## P0171-FUEL SYSTEM 1/1 LEAN — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 4 | Turn the ignition off.<br>**NOTE: Wait a minimum of 10 minutes to allow the O2 Sensor to cool down before continuing the test. Allow the O2 Sensor voltage to stabilize at 5.0 volts.**<br>**NOTE: Perform the following test on all O2 Sensors.**<br>Ignition on, engine not running.<br>With the DRBIII®, actuate the O2 Heater Test.<br>With the DRBIII®, monitor O2 Sensor voltage for at least 2 minutes.<br>Does the voltage stay above 4.5 volts?<br>Yes → Replace the O2 Sensor.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5.<br>No → Go To 5 | All |
| 5 | With the DRBIII®, read TP Sensor voltage.<br>**NOTE: The throttle must be against the stop.**<br>Is the voltage 0.92 or less with the Throttle closed?<br>Yes → Go To 6<br>No → Check for a binding throttle condition. If OK, replace the Throttle Position Sensor.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |
| 6 | With the DRBIII®, read the TP Sensor voltage.<br>While monitoring the DRBIII®, slowly open and close the throttle.<br>Does the voltage increase and decrease smoothly?<br>Yes → Go To 7<br>No → Replace the Throttle Position Sensor.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |
| 7 | Turn the ignition off.<br>Connect a Vacuum Gauge to a Manifold Vacuum source.<br>Start the engine.<br>Allow the engine to idle.<br>**NOTE: If engine will not idle, maintain a constant RPM above idle.**<br>With the DRBIII® in Sensors, read the MAP Sensor vacuum value.<br>Is the DRBIII® reading within 1″ of the Vacuum Gauge reading?<br>Yes → Go To 8<br>No → Replace the MAP Sensor.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |