Symptom:

P0452-NVLD PRESSURE SWITCH STUCK CLOSED

When Monitored and Set Condition:

P0452-NVLD PRESSURE SWITCH STUCK CLOSED

When Monitored: Immediately after the engine has been started.

Set Condition: The PCM activates the NLVD Solenoid. If PCM does not see NVLD switch open an error is detected. One Trip Fault.

POSSIBLE CAUSES
GOOD TRIP EQUAL TO ZERO
EVAP PURGE SOLENOID LEAKS/STUCK OPEN
(K52) EVAP PURGE SOL CONTROL CIRCUIT SHORTED TO GROUND
NVLD SWITCH OPERATION
NVLD ASSEMBLY
(K107) NVLD SWITCH SIGNAL CIRCUIT SHORTED TO GROUND
PCM

TEST	ACTION	APPLICABILITY
1	Check for any related TSBs before continuing. Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. Is the Good Trip Counter displayed and equal to zero? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
2	Turn the ignition off. Disconnect the EVAP Purge Solenoid harness connector. Ignition on, engine not running. Using a 12-volt test light, jump across the EVAP Purge Solenoid harness connector. With the DRBIII®, actuate the EVAP Purge Solenoid. Does the test light flash on and off? Yes → Go To 3 No → Go To 7	All