Symptom:

P0499-NVLD CANISTER VENT VALVE SOLENOID CIRCUIT HIGH

When Monitored and Set Condition:

P0499-NVLD CANISTER VENT VALVE SOLENOID CIRCUIT HIGH

When Monitored: Engine running.

Set Condition: The PCM detects an open in the NVLD Canister vent solenoid circuits. One trip Fault.

POSSIBLE CAUSES
GOOD TRIP EQUAL TO ZERO
NVLD SOLENOID
(K106) NVLD SOL CONTROL CIRCUIT SHORTED TO BATTERY VOLTAGE
(K106) NVLD SOL CONTROL CIRCUIT OPEN
(Z913) GROUND CIRCUIT OPEN
PCM

TEST	ACTION	APPLICABILITY
1	Check for any related TSBs before continuing. Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. Is the Good Trip Counter displayed and equal to zero? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
2	Turn the ignition off. Disconnect the NVLD Assembly harness connector. Measure the resistance of the NVLD Solenoid coil. Is the resistance between 7.5 and 8.5 ohms? Yes → Go To 3 No → Replace the NVLD Assembly. Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
3	Disconnect the C3 PCM harness connector. Measure the voltage on the (K106) NVLD Sol Control circuit in the NVLD Assembly harness connector. Is the voltage above 1.0 volt? Yes → Repair the short to voltage in the (K106) NVLD Sol Control circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 4	All