P0509-IAC VALVE SIGNAL CIRCUIT HIGH — Continued

TEST	ACTION	APPLICABILITY
3	With the DRBIII®, actuate the ASD Relay. Measure the voltage on the (K961) IAC Signal circuit in the IAC Motor harness connector. Is the voltage above 0.5 of a volt? Yes → Repair the short to voltage in the (K961) IAC Signal circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 4	All
4	Measure the voltage on the (K61) IAC Control circuit in the IAC Motor harness connector. Is the voltage above 0.5 of a volt? Yes → Repair the short to voltage in the (K61) IAC Control circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 5 **NOTE: Stop the ASD Relay actuation before continuing.**	All
5	Turn the ignition off. Disconnect the C2 PCM harness connector. Measure the resistance across the (K961) IAC Signal circuit and the (K61) IAC Control circuit in the IAC Motor harness connector. Is the resistance below 5.0 ohms? Yes → Repair the short between the (K61) IAC Control circuit and the (K961) IAC Signal circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 6	All
6	**NOTE: Before continuing, check the PCM harness connector terminals for corrosion, damage, or terminal push out. Repair as necessary.** Using the schematics as a guide, inspect the wire harness and connectors. Pay particular attention to all Power and Ground circuits. If there are no possible causes remaining, view repair. Repair Replace and program the Powertrain Control Module per Service Information. Perform POWERTRAIN VERIFICATION TEST VER - 5.	All