*CHECKING A/C SYSTEM OPERATION WITH NO DTCS — Continued

TEST	ACTION	APPLICABILITY
4	Verify the Low Pressure Switch operation per Service Information. Is the Low Pressure Switch OK? Yes → Go To 5 No → Replace the Low Pressure Switch. Perform POWERTRAIN VERIFICATION TEST VER - 2.	All
5	Ignition on, engine not running. Position the Mode switch on the A/C - Heater Control Module to the Panel position. With the DRBIII® in BCM, select Inputs/Outputs. Monitor the A/C Select Switch state while pressing the A/C mode switch on and off. Does the A/C Select Switch state change accordingly. Yes → Go To 6 No → Go To 13	All
6	Position the Mode switch on the A/C - Heater Control Module to the Panel position. With the DRBIII® in Powertrain, select Engine and select Inputs/Outputs. Monitor the A/C Select Switch state while pressing the A/C mode switch on and off. Does the A/C Select Switch state change accordingly. Yes → Go To 7 No → Replace and program the Powertrain Control Module per Service Information. Perform POWERTRAIN VERIFICATION TEST VER - 2.	All
7	Connect a test light between the ground circuit and the A/C Clutch Relay Output circuit. With the DRBIII®, actuate the A/C Clutch Relay. Does the test light illuminate brightly on and off with the relay actuation? Yes → Replace the A/C Clutch Coil. Perform POWERTRAIN VERIFICATION TEST VER - 2. No → Go To 8	All
8	Turn the ignition off. Disconnect the A/C Clutch harness connector. **NOTE: Check connectors - Clean/repair as necessary.** Measure the resistance between ground and the A/C Compressor Clutch ground circuit in the A/C Clutch harness connector. Is the resistance below 5.0 ohms? Yes → Go To 9 No → Repair the open in the A/C Compressor Clutch ground circuit. Perform POWERTRAIN VERIFICATION TEST VER - 2.	All
9	Turn the ignition off. Remove the A/C Clutch Relay. **Note: Check connectors - Clean/repair as necessary.** Measure the resistance of the (C3) A/C Clutch Relay Output circuit between the Relay and the A/C Clutch Coil. Is the resistance below 5.0 ohms? Yes → Go To 10 No → Repair the open in the (C3) A/C Clutch Relay Output circuit. Perform POWERTRAIN VERIFICATION TEST VER - 2.	All