Symptom:
*CHECKING HARD START (FUEL DELIVERY SYSTEM)

POSSIBLE CAUSES
RESTRICTED FUEL SUPPLY LINE
FUEL PUMP MODULE
FUEL PUMP INLET STRAINER PLUGGED
FAULTY FUEL PUMP MODULE
FUEL INJECTORS
FUEL CONTAMINATION

TEST	ACTION	APPLICABILITY
1	Turn the ignition off. **WARNING: The fuel system is under a constant pressure even with the engine off. Before testing or servicing any fuel system hose, fitting or line, the fuel system pressure must be released.** Install the fuel pressure gauge at the engine. Refer to the Service Information FUEL DELIVERY Section. Ignition on, engine not running. With the DRBIII®, actuate the ASD Fuel System test and observe the fuel pressure gauge. **NOTE: Fuel pressure specification is 400 KPa +/- 34 KPa (58 psi +/- 5 psi).** Choose a conclusion that best matches your fuel pressure reading. Below Specification Go To 2 Within Specification Go To 4	All
2	Turn the ignition off. **WARNING: The fuel system is under a constant pressure even with the engine off. Before testing or servicing any fuel system hose, fitting or line, the fuel system pressure must be released.** Raise vehicle on hoist, and disconnect the fuel supply line at the fuel pump module. Install special tool #6539 (5/16″) fuel line adapter fuel pressure gauge between the fuel supply line and the fuel pump module. Ignition on, engine not running. With the DRBIII®, actuate the ASD Fuel System test and observe the fuel pressure gauge. **NOTE: Fuel pressure specification is 400 KPa +/- 34 KPa (58 psi +/- 5 psi).** Is the fuel pressure within specification? Yes → Visually and physically inspect the fuel supply lines between the fuel tank and the fuel rail. Repair/replace as necessary. Perform POWERTRAIN VERIFICATION TEST VER - 2. No → Go To 3	All