## P0706-CHECK SHIFTER SIGNAL — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 1 | **NOTE: Low fluid level can be the cause of many Transmission problems. If the fluid level is low, locate and repair the leak, then check and adjust the fluid level per the Service Information.**<br>**NOTE: Always perform diagnostics with a fully charged battery to avoid false symptoms.**<br>With the DRBIII®, read the engine DTC's. Check and repair all engine DTC's prior to performing Transmission Symptom Diagnostics.<br>With the DRBIII®, read Transmission DTC's. Record all DTC's and 1 Trip Failures.<br>**NOTE: Diagnose 1 Trip Failures as a fully matured DTC.**<br>Using the wiring diagram/schematic as a guide, inspect the wiring and connectors. Repair as necessary.<br>Perform the Shift Lever Position Test. If the test does not pass, refer to Symptom test for P0706 Check Shifter Signal.<br>For Gear Ratio DTC's, check and record all CVI's.<br>Most DTC's set on start up but some must be set by driving the vehicle such that all diagnostic monitors have run.<br>**NOTE: Verify flash level of Transmission Control Module. Some problems are corrected by software upgrades to the Transmission Control Module.**<br>**NOTE: Check for applicable TSB's related to the symptom.**<br>Perform this procedure prior to Symptom diagnosis.<br><br>Continue<br>Go To 2 | All |
| 2 | Using the DRBIII®, perform the Shift Lever Position Test.<br>Select the test outcome from the following:<br><br>Test passes<br>Go To 3<br><br>Test fails with DTC<br>Go To 4<br><br>Test fails without DTC<br>Adjust the shift linkage per the Service Information.<br>Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1. | All |
| 3 | The conditions necessary to set this DTC are not present at this time.<br>Using the schematics as a guide, inspect the wiring and connectors specific to this circuit.<br>Wiggle the wiring while checking for shorts and open circuits.<br>With the DRBIII®, check the EATX EVENT DATA to help identify the conditions in which the DTC was set.<br>Were there any problems found?<br><br>Yes → Repair as necessary.<br>Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1.<br><br>No → Test Complete. | All |