FUSES (PDC)

FUSE NO.	AMPS	FUSED CIRCUIT	FUNCTION
1	40A	A502 12RD/LG	FUSED B(+)
2	40A	A902 12RD	FUSED B(+)
3	40A	A906 12RD	FUSED B(+)
4	40A	A16 12GY (2.4L)	FUSED B(+)
5	20A	A30 16RD/WT (A/T)	FUSED B(+)
6	40A	A8 14RD	FUSED B(+)
7	-	-	-
8	40A	A107 12TN/RD (ABS)	FUSED B(+)
9	20A	A209 18RD/YL	FUSED B(+)
9	20A	A209 18RD (42RLE)	FUSED B(+)
9	20A	A209 18RD/YL (NA1)	FUSED B(+)
10	40A	A940 12RD	FUSED B(+)
11	-	-	-
12	30A	A111 12DG/RD (ABS)	FUSED B(+)
13	40A	A991 12RD	FUSED B(+)
14	-	-	-
15	50A	INTERNAL	FUSED B(+)
16	-	-	-
17	20A	A205 18RD/OR	FUSED B(+)
18	20A	A43 18RD/DG	FUSED B(+)
18	20A	A43 18RD/DG	FUSED B(+)
19	20A	A39 18RD/DG (OPTION 1)	FUSED B(+)
19	20A	A39 16RD/DG (OPTION 2)	FUSED B(+)
20	15A	F306 16DB/PK	FUSED B(+)
21	10A	A926 20RD	FUSED B(+)
22	25A	A1 16RD	FUSED B(+)
23	20A	A930 18RD	FUSED B(+)
24	20A	INTERNAL (OFF-ROAD PACKAGE)	FUSED B(+)
25	-	-	-
26	10A	M21 20YL/BR	FUSED B(+)
27	20A	A701 18BR/RD	FUSED B(+)
28	10A	Y3 18LG	FUSED SENSOR GROUND
28	10A	K900 20DB/DG	SENSOR GROUND
28	10A	Y3 20LG	FUSED SENSOR GROUND

A/C COMPRESSOR CLUTCH RELAY (IN PDC)

CAV	CIRCUIT	FUNCTION
A6	F960 20PK/LG	FUSED IGNITION SWITCH OUTPUT (RUN-START)
A6	F960 20PK/LG (2.4L)	FUSED IGNITION SWITCH OUTPUT (RUN-START)
A7	-	-
A8	C13 20LB/OR	A/C CLUTCH RELAY CONTROL
A9	C3 20DB/YL	A/C CLUTCH RELAY OUTPUT
A10	A926 20RD	FUSED B(+)

AUTOMATIC SHUT DOWN RELAY (IN PDC)

CAV	CIRCUIT	FUNCTION
A11	K342 20BR/WT	ASD RELAY CONTROL
A12	-	-
A13	F1 20PK/WT	FUSED IGNITION SWITCH OUTPUT (RUN-START)
A13	F1 20PK/WT	FUSED IGNITION SWITCH OUTPUT (RUN-START)
A14	K334 18BR	ASD RELAY OUTPUT
A15	A209 18RD/YL	FUSED B(+)