ENGINE STARTER MOTOR RELAY (IN PDC)

CAV	CIRCUIT	FUNCTION
B1	A8 14RD	FUSED B(+)
B2	T750 14YL/GY	ENGINE STARTER MOTOR RELAY OUTPUT
B3	T752 20DG/OR	STARTER MOTOR RELAY CONTROL
B4	-	-
B5	F26 16PK/OR	IGNITION SWITCH OUTPUT (START)

FUEL PUMP RELAY (IN PDC)

CAV	CIRCUIT	FUNCTION
C6	F1 20PK/WT	FUSED IGNITION SWITCH OUTPUT (RUN-START)
C6	F1 20PK/WT	FUSED IGNITION SWITCH OUTPUT (RUN-START)
C7	-	-
C8	K31 20BR	FUEL PUMP RELAY CONTROL
C9	A109 18OR/RD	FUEL PUMP RELAY OUTPUT
C10	A930 18RD	FUSED B(+)

HIGH SPEED RADIATOR FAN RELAY (2.4L)

CAV	CIRCUIT	FUNCTION
D10	A16 12GY	FUSED B(+)
D11	N112 20DB/OR	HIGH SPEED RADIATOR FAN RELAY CONTROL
D13	F960 20PK/LG	FUSED IGNITION SWITCH OUTPUT (RUN-START)
D14	C25 12YL	HIGH SPEED RADIATOR RELAY OUTPUT

LOW SPEED RADIATOR FAN RELAY (2.4L)

CAV	CIRCUIT	FUNCTION
D2	A16 12GY	FUSED B(+)
D4	F960 20PK/LG	FUSED IGNITION SWITCH OUTPUT (RUN-START)
D4	F960 20PK/LG	FUSED IGNITION SWITCH OUTPUT (RUN-START)
D6	N201 20DB/LG	LOW SPEED RADIATOR FAN RELAY CONTROL
D8	C23 12DG	LOW SPEED FAN RELAY OUTPUT

TRANSMISSION CONTROL RELAY (IN PDC)

CAV	CIRCUIT	FUNCTION
A1	A30 16RD/WT	FUSED B(+)
A2	T515 20YL/DB	TRANSMISSION CONTROL RELAY CONTROL
A3	T16 18YL/OR	TRANSMISSION CONTROL RELAY OUTPUT
A4	Z901 18BK	GROUND
A5	-	-