IGNITION CONTROL

TABLE OF CONTENTS

page

IGNITION CONTROL
DESCRIPTION 1
OPERATION 1
SPECIFICATIONS
SPECIFICATIONS - IGNITION TIMING 2
ENGINE FIRING ORDER - 2.4L 4-CYLINDER . 2
ENGINE FIRING ORDER - 4.0L 6-CYLINDER ENGINE 2
IGNITION COIL RESISTANCE - 2.4L 3
IGNITION COIL RESISTANCE - 4.0L ENGINE . 3
SPARK PLUGS 3
SPECIFICATIONS - SPARK PLUG CABLE RESISTANCE 3
SPECIFICATIONS - TORQUE - IGNITION SYSTEM 4
AUTO SHUT DOWN RELAY
DESCRIPTION - PCM OUTPUT 4
OPERATION
OPERATION - ASD SENSE - PCM INPUT 4
OPERATION - PCM OUTPUT 4
DIAGNOSIS AND TESTING - ASD AND FUEL PUMP RELAYS 4
REMOVAL 5
INSTALLATION 6
CAMSHAFT POSITION SENSOR - 2.4L
DESCRIPTION - 2.4L 6
OPERATION - 2.4L 6
REMOVAL - 2.4L 6
INSTALLATION - 2.4L 6

page

CAMSHAFT POSITION SENSOR - 4.0L
DESCRIPTION - 4.0L 8
OPERATION - 4.0L 8
REMOVAL - 4.0L 9
INSTALLATION - 4.0L 10
COIL RAIL - 4.0L
DESCRIPTION - 4.0L 12
OPERATION - 4.0L 12
REMOVAL - 4.0L 13
INSTALLATION - 4.0L 14
IGNITION COIL - 2.4L
DESCRIPTION - 2.4L 14
OPERATION - 2.4L 14
REMOVAL - 2.4L 15
INSTALLATION - 2.4L 15
SPARK PLUG
DESCRIPTION 15
OPERATION 15
DIAGNOSIS AND TESTING - SPARK PLUG CONDITIONS 15
REMOVAL 18
CLEANING SPARK PLUGS 18
INSTALLATION 18
SPARK PLUG CABLE
DESCRIPTION 19
OPERATION 19
DIAGNOSIS AND TESTING 19
REMOVAL - 2.4L 19
INSTALLATION 19

IGNITION CONTROL

DESCRIPTION

The ignition systems used on both the 2.4L 4–cylinder and 4.0L 6–cylinder engines are a distributorless type.

The ignition system consists of:

- Spark Plugs
- Spark Plug Cables (secondary wires)
- Ignition Coil(s)
- Powertrain Control Module (PCM)
- Crankshaft Position Sensor
- Camshaft Position Sensor
- The MAP, TPS, IAC and ECT also have an effect on the control of the ignition system.

OPERATION

2.4L

A common ignition coil divided into 2 halves is used. Secondary, high-tension spark plug cables are also used. One half of the coil fires two spark plugs simultaneously (one plug is the cylinder under compression, and the other plug is the cylinder on the exhaust stroke). Coil half number one fires cylinders 1 and 4. Coil half number two fires cylinders 2 and 3. The PCM determines which of the coils to charge and fire at the correct time.