REAR WIPERS/WASHERS

TABLE OF CONTENTS

page

REAR WIPERS/WASHERS
DESCRIPTION 24
OPERATION 26
DIAGNOSIS AND TESTING - REAR WIPER & WASHER SYSTEM 27
CLEANING - REAR WIPER & WASHER SYSTEM 28
INSPECTION - REAR WIPER & WASHER SYSTEM 29
REAR CHECK VALVE
DESCRIPTION 30
OPERATION 30
REMOVAL 31
INSTALLATION 31
REAR WASHER HOSES/TUBES
DESCRIPTION 31
OPERATION 32
REAR WASHER NOZZLE
DESCRIPTION 32
OPERATION 32
REMOVAL 33
INSTALLATION 33
REAR WASHER PUMP MOTOR
DESCRIPTION 33
OPERATION 34
REMOVAL 34
INSTALLATION 34
REAR WIPER ARM
DESCRIPTION 34
OPERATION 35
REMOVAL 35
INSTALLATION 35
REAR WIPER BLADE
DESCRIPTION 36
OPERATION 37
REMOVAL 37
INSTALLATION 37
REAR WIPER MOTOR
DESCRIPTION 37
OPERATION 38
REMOVAL 38
INSTALLATION 39
REAR WIPER MOTOR TRIM COVER
REMOVAL 39
INSTALLATION 40
REAR WIPER/WASHER SWITCH
DESCRIPTION 40
OPERATION 40
DIAGNOSIS AND TESTING - REAR WIPER & WASHER SWITCH 41
REMOVAL 41
INSTALLATION 42

REAR WIPERS/WASHERS

DESCRIPTION

An electrically operated fixed speed rear wiper and washer system is optional factory-installed equipment on this model when it is also equipped with the optional hardtop roof (Fig. 1). The rear wiper and washer system includes the following major components, which are described in further detail elsewhere in this service information:

- **Rear Check Valve** - The rear washer system check valve is located near the belt line in the left rear corner of the passenger compartment in the vehicle. The rear check valve also serves as the in-line connector between the body wire harness half and the hardtop wire harness half of the rear washer hose plumbing.
- **Rear Washer Nozzle** - The rear washer nozzle is located in a mounting hole in the rear liftglass just below and inboard of the rear wiper motor output shaft. A plastic nut secures the threaded nipple on the back of the nozzle to the inside of the liftglass.
- **Rear Washer Plumbing** - The plumbing for the rear washer system consists of rubber hoses and molded plastic fittings. The plumbing is routed along the left side of the vehicle with the body wire harness from the washer reservoir in the engine compartment, through the dash into the passenger compartment, and back to the left rear corner of the body. The rear check valve splices the body wire harness half of the washer hose to the hardtop wire harness half of the hose at the left rear corner of the body. The hardtop wire harness and washer hose are routed up the left rear corner of the hardtop and over the upper liftglass opening header to the rear washer nozzle in the upper right corner of the rear liftglass. A molded plastic washer hose cap is secured by an integral bail strap to the body wire harness half of the rear washer hose near the left rear corner of the body. This cap serves to plug the rear washer hose when the hardtop is removed from the vehicle.