8W-02 COMPONENT INDEX

Component	Page
A/C Compressor Clutch	8W-42
A/C Compressor Clutch Relay	8W-42
A/C High Pressure Switch	8W-42
A/C Low Pressure Switch	8W-42
A/C Pressure Transducer	8W-42
A/C-Heater Control	8W-42
Airbag Control Module	8W-43
Airbag On-Off Switch	8W-43
Airbag Squibs	8W-43
Ambient Temperature Sensor	8W-30, 44
Antilock Brake Relay	8W-35
Automatic Shut Down Relay	8W-30
Axle Lock Switch	8W-31
Back-Up Lamp Switch	8W-51
Battery	8W-10
Battery Temperature Sensor	8W-30
Blend Door Actuator	8W-42
Blower Motor	8W-42
Blower Motor Relay	8W-42
Blower Motor Resistor Block	8W-42
Brake Lamp Switch	8W-51
Brake Transmission Shift Interlock Solenoid	8W-31
Brake Warning Indicator Switch	8W-40
Camshaft Position Sensor	8W-30
Center High Mounted Stop Lamp	8W-51
Cigar Lighter/Power Outlet	8W-41
Circuit Breaker	8W-50
Clockspring	8W-33, 41, 43
Clutch Pedal Position Switch	8W-21
Coil Capacitor	8W-30
Compass/Temperature Mirror	8W-44
Controller Antilock Brake	8W-35
Courtesy Lamps	8W-44
Crankshaft Position Sensor	8W-30
Data Link Connector	8W-18
Daytime Running Lamp Module	8W-50
Dome Lamps	8W-44
Door Ajar Switches	8W-44
Engine Coolant Temperature Sensor	8W-30
Engine Oil Pressure Sensor	8W-30
Engine Oil Pressure Switch	8W-30
Engine Starter Motor	8W-21
Engine Starter Motor Relay	8W-21
EVAP/Purge Solenoid	8W-30
Fog Lamp Relay	8W-50
Fog Lamps	8W-50
Fuel Injectors	8W-30
Fuel Pump Module	8W-30
Fuel Pump Relay	8W-30
Fuse Block	8W-11
Fuses	8W-10, 11
Fusible Link	8W-20
G-Switch	8W-35
Generator	8W-20
Grounds	8W-15
Headlamp Leveling Motors	8W-50
Headlamp Leveling Switch	8W-50
Headlamps	8W-50
Heater Control	8W-42
High Speed Radiator Fan Relay	8W-42
Horn	8W-41
Horn Relay	8W-41
Horn Switch	8W-41
Idle Air Control Motor	8W-30
Ignition Coil Pack	8W-30
Ignition Switch	8W-10
Instrument Cluster	8W-40
Intake Air Temperature Sensor	8W-30
Lamp Assemblies	8W-51
License Lamps	8W-51
Locker Indicator Switches	8W-31
Locker Pumps	8W-31
Locker Relays	8W-31
Low Speed Radiator Fan Relay	8W-42
Manifold Absolute Pressure Sensor	8W-30
Multi-Function Switch	8W-44, 50, 51, 52, 53
Natural Vacuum Leak Detection Assembly	8W-30
Oxygen Sensors	8W-30
Park Brake Switch	8W-40
Park/Turn Signal Lamps	8W-52
Position Lamps	8W-50
Power Distribution Center	8W-10
Power Outlet	8W-41
Power Steering Pressure Switch	8W-30
Powertrain Control Module	8W-30, 31
Radiator Fan Motor	8W-42
Radiator Fan Motor Circuit Breaker	8W-42
Radio	8W-47
Rear Fog Lamp	8W-51
Rear Window Defogger	8W-48
Rear Window Defogger Relay	8W-48
Rear Window Defogger Switch	8W-48
Rear Wiper/Washer Switch	8W-53
Seat Belt Switch	8W-40
Sentry Key Immobilizer Module	8W-39
Side Marker Lamps	8W-50
Side Repeater Lamps	8W-52
Speakers	8W-47
Speed Control Servo	8W-33
Speed Control Switches	8W-33
Speed Sensors	8W-31
Splices	8W-70
Subwoofer	8W-47