8W-48 REAR WINDOW DEFOGGER

Component	Page
Fuse 2	8W-48-2
Fuse 7	8W-48-2
Fuse 15	8W-48-2
Fuse Block	8W-48-2, 3
G200	8W-48-3
G302	8W-48-3
Instrument Cluster	8W-48-2, 3
Power Distribution Center	8W-48-2
Rear Window Defogger	8W-48-2, 3
Rear Window Defogger Relay	8W-48-2
Rear Window Defogger Switch	8W-48-3