Component	Page
Intake Air Temperature Sensor (2.4L)	8W-80-32
Left Courtesy Lamp	8W-80-32
Left Dome Lamp	8W-80-33
Left Fog Lamp (Except Export)	8W-80-33
Left Front Park/Turn Signal Lamp	8W-80-33
Left Front Position Lamp (Export)	8W-80-33
Left Front Speaker	8W-80-34
Left Front Turn Signal Lamp (Export)	8W-80-34
Left Front Wheel Speed Sensor	8W-80-34
Left Headlamp	8W-80-34
Left Headlamp Leveling Motor (Export)	8W-80-34
Left License Lamp (Export)	8W-80-35
Left Rear Lamp Assembly	8W-80-35
Left Rear Speaker	8W-80-35
Left Rear Wheel Speed Sensor	8W-80-35
Left Side Marker Lamp (Except Export)	8W-80-36
Left Side Repeater Lamp (Export)	8W-80-36
Manifold Absolute Pressure Sensor	8W-80-36
Multi-Function Switch C1	8W-80-37
Multi-Function Switch C2	8W-80-37
Natural Vacuum Leak Detection Assembly	8W-80-37
Output Speed Sensor (A/T)	8W-80-38
Oxygen Sensor 1/1 Upstream (2.4L)	8W-80-38
Oxygen Sensor 1/1 Upstream (4.0L)	8W-80-38
Oxygen Sensor 1/2 Downstream	8W-80-38
Oxygen Sensor 2/1 Upstream (4.0L)	8W-80-39
Oxygen Sensor 2/2 Downstream (4.0L)	8W-80-39
Passenger Airbag On-Off Switch (LHD)	8W-80-39
Passenger Airbag Squib 1	8W-80-39
Passenger Door Ajar Switch	8W-80-40
Power Outlet	8W-80-40
Power Steering Pressure Switch (2.4L)	8W-80-40
Powertrain Control Module C1	8W-80-41
Powertrain Control Module C2	8W-80-42
Powertrain Control Module C3	8W-80-43
Powertrain Control Module C4	8W-80-44
Radiator Fan Motor (2.4L)	8W-80-45
Radiator Fan Motor Circuit Breaker (2.4L)	8W-80-45
Radio	8W-80-45
Rear Fog Lamp (Export)	8W-80-46
Rear Locker Indicator Switch (Off-Road Package)	8W-80-46
Rear Locker Pump (Off-Road Package)	8W-80-46
Rear Washer Pump (Hard Top)	8W-80-46
Rear Window Defogger Switch (Hard Top)	8W-80-47
Rear Wiper Motor (Hard Top)	8W-80-47
Rear Wiper/Washer Switch (Hard Top)	8W-80-47
Right Courtesy Lamp	8W-80-47
Right Dome Lamp	8W-80-48
Right Fog Lamp (Except Export)	8W-80-48
Right Front Park/Turn Signal Lamp	8W-80-48
Right Front Position Lamp (Export)	8W-80-48
Right Front Speaker	8W-80-48
Right Front Turn Signal Lamp (Export)	8W-80-49
Right Front Wheel Speed Sensor	8W-80-49
Right Headlamp	8W-80-49
Right Headlamp Leveling Motor (Export)	8W-80-49
Right License Lamp (Export)	8W-80-49
Right Rear Lamp Assembly	8W-80-50
Right Rear Speaker	8W-80-50
Right Rear Wheel Speed Sensor	8W-80-50
Right Side Marker Lamp (Except Export)	8W-80-50
Right Side Repeater Lamp (Export)	8W-80-51
Seat Belt Switch (Except LHD Export)	8W-80-51
Sentry Key Immobilizer Module	8W-80-51
Speed Control Servo	8W-80-51
Subwoofer	8W-80-52
Throttle Position Sensor (2.4L)	8W-80-52
Throttle Position Sensor (4.0L)	8W-80-52
Torque Converter Clutch Solenoid	8W-80-52
Tow/Haul Overdrive Off Switch	8W-80-53
Transfer Case Switch (Except Off-Road Package)	8W-80-53
Transfer Case Switch (Off-Road Package)	8W-80-53
Transmission Range Indicator Illumination (PRNDL)	8W-80-53
Transmission Range Sensor	8W-80-54
Transmission Solenoid/Pressure Switch Assembly	8W-80-54
Underhood Lamp	8W-80-54
Variable Line Pressure Sensor	8W-80-55
Vehicle Speed Sensor	8W-80-55