CONNECTOR/GROUND/SPLICE LOCATION (Continued)

GROUNDS

Connector Name/ Number	Location	Fig.
G100	Rear Center of Engine Compartment	10, 12
G101	Rear Center of Engine Compartment	10, 12
G102	Left Radiator Closure Panel	1
G103	Right Radiator Closure Panel	2
G104	Near Generator	N/S
G105	Right Rear of Engine Block (4.0L) Near Left Engine Mount (2.4L)	4, 7
G106	Rear of Engine Compartment	3, 11
G107	Left Front of Engine Block	3, 8, 11
G108	Right Rear Engine Block	8
G110 (2.4L)	Near Left Engine Mount	4
G111	Near Right Rear of Engine	N/S
G190	Near Right Headlamp	2
G191	Near Right Headlamp	N/S
G200 (LHD)	Left Rear of Instrument Panel	24
G200 (RHD)	Right Rear of Instrument Panel	27
G201 (LHD)	Left Rear of Instrument Panel	24
G201 (RHD)	Right Rear of Instrument Panel	27
G202 (LHD)	Right Rear of Instrument Panel	25
G202 (RHD)	Left Rear of Instrument Panel	27
G203 (LHD)	Right Rear of Instrument Panel	25
G203 (RHD)	Left Rear of Instrument Panel	27
G204	Center of Instrument Panel	25, 27
G300 (LHD)	Left Kick Panel	22
G300 (RHD)	Right Kick Panel	23
G301 (LHD)	At Base of Center Stack	20
G301 (RHD)	Left Kick Panel	21
G302 (LHD)	Left Kick Panel	22
G302 (RHD)	Right Kick Panel	23
G303 (LHD)	Near Steering Column Mounting Bracket	30