CONNECTOR/GROUND/SPLICE LOCATION (Continued)

SPLICES

Splice Number	Location	Fig.
S101	Near T/O for Power Distribution Center	10, 12
S102	Near T/O for G100 or Daytime Running Lamp Module	10
S103	Near T/O for G101	10, 12
S105	Left Cowl Panel	22
S106	Near T/O for G100	10
S108	Near T/O for Powertrain Control Module	10, 12
S111	Near T/O for Battery Temperature Sensor or Power Distribution Center	10
S117	Near T/O for Horn	1
S122	Near Grommet for Left Front Turn Signal Lamp, See Right	2
S123 (4.0L)	Near T/O for G105	N/S
S123 (2.4L)	Near T/O for Ignition Coil Pack	N/S
S125 (Export)	Near Grommet for Right Front Turn Signal Lamp	2
S126	Near T/O for C104	7
S127	Rear Engine Compartment	9, 17
S128 (4.0L)	Between Fuel Injector NO. 2 and Fuel Injector NO. 3	5
S128 (2.4L)	Near T/O for C103 on Engine Harness	N/S
S129	Rear of Engine	4, 7, 35
S130 (4.0L)	Left Rear of Engine	5
S130 (2.4L)	Near T/O for C103 on Engine Harness	N/S
S131	Left Rear Engine	7
S132 (4.0L)	Top of Transmission	7, 35
S132 (2.4L)	Near T/O for Engine Starter Solenoid	4
S133 (4.0L)	Trans Harness	7
S133 (2.4L)	Near T/O for Input Speed Sensor	4
S134 (4.0L)	Top Front of Engine	5
S134 (2.4L)	Between Engine Starter Solenoid and C182	N/S
S135 (2.4L)	Rear of Engine	4
S135 (4.0L)	In T/O for PCM	9
S136	In Battery harness near PDC	N/S
S137	Near T/O for Throttle Position Sensor	N/S
S138	Left Engine Compartment	13, 14
S140	Near T/O for C104	N/S
S141	Near T/O for Left Front Turn Signal Lamp, See Right	2
S142	Near T/O for Right Front Turn Signal Lamp	2
S143	Rear of Engine Compartment	10, 12
S144	Near T/O for Right Front Park/Turn Signal Lamp	N/S
S147	Between T/O's for Underhood Lamp and C103, C104	10, 12
S150	Right Headlamp T/O	2
S151	Left Rear Engine Compartment	14
S151 (RHD)	Left Side Engine Compartment	13