CONNECTOR/GROUND/SPLICE LOCATION (Continued)

Splice Number	Location	Fig.
S152	Left Rear Engine Compartment	14
S152 (RHD)	Right Rear Engine Compartment	12
S153	Rear Engine Compartment	7, 17
S155	Left Rear Engine Compartment	10, 12
S156	Near T/O for ABS Pump Motor	10
S158 (2.4L)	Near T/O For Power Steering Pressure Switch	N/S
S159 (2.4L)	In T/O for PCM	4, 9
S160 (2.4L)	Left Rear Engine Compartment	4
S160 (4.0L)	Front of Transmission	5, 7
S161	Rear of Engine Compartment	9, 17
S162 (2.4L)	Near T/O for Oxygen Sensor 1/1 Upstream	N/S
S164	Near T/O For Rer Locker Indicator Switch Inline C116	32
S170	Rear of Engine Compartment	10, 12
S172	Between G100 and C103	10, 12
S173	Near G100	10, 12
S176	In Fuel InjectorHarness	N/S
S177	Rear of Engine Compartment	7, 17
S178	Near T/O for C103 on Engine Harness	N/S
S180 (LHD)	In PDC	10
S180 (RHD)	Left Rear Engine Compartment	12
S184	Left Side of Engine	5
S185	Rear of Engine	7
S202 (LHD)	Center of Instrument Panel	24, 26
S202 (RHD)	Center Rear of Instrument Panel	26, 27
S204	Center Rear of Instrument Panel	26, 27
S206	Center Rear of Instrument Panel	26, 27
S207	Near Cigar Lighter T/O	26, 29
S208	Near Blower Motor	N/S
S209	Near T/O for C202, C203, and C204	24, 26, 27, 28
S210	Near T/O for A/C Heater Control C3	26, 29
S211	Near T/O for C202	N/S
S212	Near T/O to Right Courtesy Lamp	N/S
S213	Center Rear of Instrument Panel	N/S
S214	Center Rear of Instrument Panel	N/S
S215	Center Rear of Instrument Panel	25, 27
S216	Left Side of Instrument Panel	24
S217	Left Side of Instrument Panel	24
S218	Driver Side Instrument Panel	24, 27
S302(LHD)	In T/O to Steering Column	19
S302(RHD)	Between S315 and S331, near T/O to ACM	21
S304 (LHD)	Center Rear of Dash Panel, Near Front Wiper Motor T/O	19
S304 (RHD)	Near T/O for C202 and C107	21, 23