CONNECTOR/GROUND/SPLICE LOCATION (Continued)




Fig. 30 -STEERING COLUMN CONNECTIONS




Fig. 31 -STEERING WHEEL CONNECTIONS