ENGINE

TABLE OF CONTENTS

page

ENGINE 2.4L 1

page

ENGINE 4.0L 68

ENGINE 2.4L

TABLE OF CONTENTS

page

ENGINE 2.4L
DESCRIPTION 3
DIAGNOSIS AND TESTING
CYLINDER COMPRESSION PRESSURE TEST 3
ENGINE DIAGNOSIS - PERFORMANCE 4
CYLINDER COMBUSTION PRESSURE LEAKAGE TEST 5
ENGINE OIL LEAK INSPECTION 6
ENGINE DIAGNOSIS 7
ENGINE MECHANICAL 7
STANDARD PROCEDURE
REPAIR OF DAMAGED OR WORN THREADS 9
HYDROSTATIC LOCKED ENGINE 9
ENGINE CORE AND OIL GALLERY PLUGS . . 10
ENGINE GASKET SURFACE PREPARATION . 10
MEASURING BEARING CLEARANCE USING PLASTIGAGE 11
FORM-IN-PLACE GASKETS AND SEALERS . 11
REMOVAL - ENGINE ASSEMBLY 12
INSTALLATION - ENGINE ASSEMBLY 13
SPECIFICATIONS
SPECIFICATIONS - 2.4L ENGINE 14
SPECIFICATIONS - TORQUE 18
SPECIAL TOOLS
2.4L ENGINE 19
AIR CLEANER ELEMENT - 2.4L
REMOVAL - 2.4L 21
INSTALLATION - 2.4L 21
AIR CLEANER HOUSING
REMOVAL 21
INSTALLATION 22
CYLINDER HEAD
DESCRIPTION 22
OPERATION 22
DIAGNOSIS AND TESTING
CYLINDER HEAD GASKET 22

page

REMOVAL - CYLINDER HEAD 23
CLEANING 23
INSPECTION 23
INSTALLATION - CYLINDER HEAD 24
CAMSHAFT OIL SEAL(S)
REMOVAL 25
INSTALLATION 26
CAMSHAFT(S)
DESCRIPTION 26
OPERATION 26
STANDARD PROCEDURE - CAMSHAFT END-PLAY 27
REMOVAL 27
CLEANING 27
INSPECTION 27
INSTALLATION 28
CYLINDER HEAD COVER
REMOVAL 28
CLEANING 28
INSPECTION 28
INSTALLATION 29
INTAKE/EXHAUST VALVES & SEATS
DESCRIPTION 30
CLEANING 30
VALVE SPRINGS
REMOVAL
REMOVAL - CYLINDER HEAD ON 30
REMOVAL - CYLINDER HEAD OFF 30
INSPECTION 31
INSTALLATION
INSTALLATION - CYLINDER HEAD ON 31
INSTALLATION - CYLINDER HEAD OFF 31
HYDRAULIC LIFTERS
DIAGNOSIS AND TESTING
LASH ADJUSTER (TAPPET) NOISE DIAGNOSIS 32
REMOVAL 32
INSTALLATION 32