FRAME & BUMPERS

TABLE OF CONTENTS

page

FRAME & BUMPERS
SPECIFICATIONS
TORQUE SPECIFICATIONS 1
FRONT EXTENSION
REMOVAL 2
INSTALLATION 2
FRONT BUMPER
REMOVAL 2
INSTALLATION 2
REAR EXTENSION
REMOVAL 2
INSTALLATION 2
REAR BUMPER
REMOVAL 2
INSTALLATION 3
FRAME
STANDARD PROCEDURE - FRAME SERVICE . . 3

page

SPECIFICATIONS
FRAME DIMENSIONS 4
TRANSFER CASE SKID PLATE
REMOVAL 9
INSTALLATION 9
FUEL TANK SKID PLATE
REMOVAL 10
INSTALLATION 10
FRONT TOW HOOK
REMOVAL 10
INSTALLATION 10
REAR TOW HOOK
REMOVAL 11
INSTALLATION 11
TRANSMISSION SKID PLATE
REMOVAL 11
INSTALLATION 11

FRAME & BUMPERS

SPECIFICATIONS

TORQUE SPECIFICATIONS

TORQUE SPECIFICATIONS

DESCRIPTION	N·m	Ft. Lbs.	In. Lbs.
FRONT BUMPER SCREW	108	80	—
FRONT TOW HOOK SCREW	108	80	—
FUEL TANK SKID PLATE NUTS	16	12	138
FUEL TANK STRAP NUTS	5	—	40
MAIN FLOOR TO HOLD DOWN BOLT	68	50	—
RADIATOR TO FRAME HOLD DOWN BOLT	60	45	—
REAR BUMPER BOLT	77	57	—
REAR FLOOR TO FRAME BOLT	47	35	—
REAR TOE HOOK SCREW	77	57	—
TRANFER CASE SKID PLATE BOLTS	45	33	—
TRANSMISSION MOUNT NUTS	35	26	—
TRANSMISSION SKID PLATE TO FRAME BOLTS	45	33	—
TRANSMISSION SKID PLATE TO TRANSFER CASE SKID PLATE BOLTS	28	21	—