FUEL DELIVERY (Continued)

SPECIAL TOOLS

FUEL SYSTEM



LOCKRING REMOVER/INSTALLER #9340



TEST KIT, FUEL PRESSURE #5069



ADAPTERS, FUEL PRESSURE TEST - #6539 AND/OR #6631

FUEL PRESSURE REGULATOR

DESCRIPTION

Refer to Fuel Pump Module for information.

O2S (OXYGEN SENSOR) REMOVER/INSTALLER - #C-4907

FUEL LEVEL SENDING UNIT / SENSOR

DESCRIPTION

Refer to Fuel Pump Module for information.

FUEL LINES

DESCRIPTION

Also refer to Quick-Connect Fittings.

WARNING: THE FUEL SYSTEM IS UNDER A CONSTANT PRESSURE (EVEN WITH THE ENGINE OFF). BEFORE SERVICING ANY FUEL SYSTEM HOSES, FITTINGS OR LINES, THE FUEL SYSTEM PRESSURE MUST BE RELEASED. REFER TO THE FUEL SYSTEM PRESSURE RELEASE PROCEDURE IN THIS GROUP.

The lines/tubes/hoses used on fuel injected vehicles are of a special construction. This is due to the higher fuel pressures and the possibility of contaminated fuel in this system. If it is necessary to replace these lines/tubes/hoses, only those marked EFM/EFI may be used.

If equipped: The hose clamps used to secure rubber hoses on fuel injected vehicles are of a special rolled edge construction. This construction is used to prevent the edge of the clamp from cutting into the hose. Only these rolled edge type clamps may be used in this system. All other types of clamps may cut into the hoses and cause high-pressure fuel leaks.

Use new original equipment type hose clamps.

FUEL PUMP

DESCRIPTION

Refer to Fuel Pump Module for information.