TIRES/WHEELS

TABLE OF CONTENTS

page

TIRES/WHEELS
DIAGNOSIS AND TESTING - TIRE AND WHEEL RUNOUT 1
STANDARD PROCEDURE
STANDARD PROCEDURE - ROTATION 2
STANDARD PROCEDURE - MATCH MOUNTING 3
STANDARD PROCEDURE - TIRE AND WHEEL BALANCE 4
TIRES
DESCRIPTION
DESCRIPTION - TIRES 5
DESCRIPTION - RADIAL-PLY TIRES 6
DESCRIPTION - TIRE INFLATION PRESSURES 6
DESCRIPTION - TIRE PRESSURE FOR HIGH SPEED 7
DESCRIPTION - REPLACEMENT TIRES 7
DIAGNOSIS AND TESTING
DIAGNOSIS AND TESTING - PRESSURE GAUGES 7
DIAGNOSIS AND TESTING - TREAD WEAR INDICATORS 7
DIAGNOSIS AND TESTING - TIRE WEAR PATTERNS 7
DIAGNOSIS AND TESTING - TIRE NOISE OR VIBRATION 8
DIAGNOSIS AND TESTING - TIRE/VEHICLE LEAD 8

page

STANDARD PROCEDURE - REPAIRING LEAKS 10
CLEANING - TIRES 10
SPECIFICATIONS
TIRE SIZE 10
SPARE TIRE
DESCRIPTION
DESCRIPTION - SPARE/TEMPORARY 10
DESCRIPTION - FULL SIZE, SPARE WHEEL WITH MATCHING TIRE 10
SPARE TIRE CARRIER
REMOVAL 11
INSTALLATION 11
WHEELS
DESCRIPTION 11
DIAGNOSIS AND TESTING - WHEEL INSPECTION 12
STANDARD PROCEDURE
STANDARD PROCEDURE - WHEEL INSTALLATION 12
STANDARD PROCEDURE - WHEEL REPLACEMENT 12
SPECIFICATIONS
TORQUE CHART 13
STUDS
REMOVAL 13
INSTALLATION 13

TIRES/WHEELS

DIAGNOSIS AND TESTING - TIRE AND WHEEL RUNOUT

Radial runout is the difference between the high and low points on the tire or wheel (Fig. 1).

Lateral runout is the **wobble** of the tire or wheel.

Radial runout of more than 1.5 mm (.060 inch) measured at the center line of the tread may cause the vehicle to shake.

Lateral runout of more than 2.0 mm (.080 inch) measured near the shoulder of the tire may cause the vehicle to shake.

Sometimes radial runout can be reduced. Relocate the wheel and tire assembly on the mounting studs (See Method 1). If this does not reduce runout to an acceptable level, the tire can be rotated on the wheel. (See Method 2).

METHOD 1 (RELOCATE WHEEL ON HUB)

(1) Drive vehicle a short distance to eliminate tire flat spotting from a parked position.

(2) Check wheel bearings and adjust if adjustable or replace if necessary.

(3) Check the wheel mounting surface.

(4) Relocate wheel on the mounting, two studs over from the original position.

(5) Tighten wheel nuts until all are properly torqued, to eliminate brake distortion.

(6) Check radial runout. If still excessive, mark tire sidewall, wheel, and stud at point of maximum runout and proceed to Method 2.

METHOD 2 (RELOCATE TIRE ON WHEEL)

NOTE: Rotating the tire on wheel is particularly effective when there is runout in both tire and wheel.