EXTERIOR

TABLE OF CONTENTS

page

BODY DECALS
DESCRIPTION 27
REMOVAL 27
INSTALLATION 27
COWL GRILLE AND SCREEN
REMOVAL 28
INSTALLATION 28
RIGHT FRONT FENDER
REMOVAL 28
INSTALLATION 28
LEFT FRONT FENDER
REMOVAL 29
INSTALLATION 29
RADIATOR GRILLE PANEL
REMOVAL 30
INSTALLATION 31
WHEELHOUSE SPLASH SHIELD
REMOVAL 31
INSTALLATION 31

page

SIDE VIEW MIRROR
REMOVAL 32
INSTALLATION 32
WHEEL OPENING FLARE MOLDING
REMOVAL 32
INSTALLATION 32
EXHAUSTER
REMOVAL 33
INSTALLATION 33
BODY SIDE GUARD
REMOVAL 33
INSTALLATION 33
SIDE STEP
REMOVAL 34
INSTALLATION 34
LICENSE PLATE BRACKET
REMOVAL 34
INSTALLATION 34

BODY DECALS

DESCRIPTION

TJ decals are durable tape decals with a adhesive backing.

To eliminate blisters and air bubbles in a decal, pierce them with a needle or pin. Force the trapped air out of the hole.

A heat gun can also be used to remove small wrinkles and irregularities in a decal.

REMOVAL

NOTE: The key to successful decal removal is to apply heat to area and slowly peel the decal from panel.

(1) Clean the surface as necessary.

(2) Place a piece of masking tape above or below the decal as a reference mark.

(3) Start at one end of the decal and apply heat with a heat gun. Slowly peel the decal from the panel by pulling it back. **Do not pull the decal outward from the panel.**

INSTALLATION

(1) The area that will be covered by the decal must be cleaned with an cleaning solution to remove any residue paint. Freshly painted surfaces must be thoroughly dry.

(2) Clean painted surface with a commercial wax and silicone removal solution. Wipe surface with a clean cloth and allow to dry.

(3) Position decal and carrier on panel and hold it in-place with pieces masking tape.

(4) Lift the bottom edge of the decal and carrier, use the tape sections as hinges, and reverse the position of the decal and carrier.

CAUTION: Always remove the carrier from the tape stripe/decal, never remove the tape stripe/decal from the carrier.

(5) Bend a corner of the carrier outward, separate the corner of the carrier from the decal.

(6) Using the masking tape on the body panel, align the decal.

(7) Separate the carrier from one end of the decal.

(8) Hold tape decal firmly against the panel surface while separating the carrier from the decal.

(9) Inspect tape decal with reflected light to check for defects that could have developed during the installation process. Remove all air and/or moisture bubbles.