OPENING DIMENSIONS (Continued)

- A. Center of radius at bottom front to center of radius at top rear.
- B. Center of door lower rear corner to center of top of windshield frame.
- C. Center of door lower rear corner to top of cowl.
- D. Center of door hinge mount to center of door striker mount.



Fig. 5 QUARTER WINDOW OPENING