
Starter [4.0L Engine]
Figure 8-110

ITEM	PART NUMBER	QTY	LINE	SERIES	BODY	ENGINE	TRANS	TRIM	DESCRIPTION
1									STARTER
	56041012AE	1				ER0	DBB		
	56041914AC	1				ER0	DG0		
2	06101848	1				ER0	DBB		SCREW AND WASHER, Hex Head, M10-1.50x30
3	06102120AA	1				ED0, ER0	DG0		SCREW AND WASHER, Hex Head



WRANGLER (TJ)

SERIES	LINE	BODY	ENGINE	TRANSMISSION
H = HIGHLINE L = LOWLINE M = MEDIUM P = PREMIUM S = SPORT	J = JEEP - 4WD U = JEEP - 4WD (RHD)	77 = OPEN BODY 2-DOOR 78 = OPEN BODY 2-DOOR	ED1 = 2.4L 4 Cyl DOHC 16v SMPI Engine ERH = 4.0L Power Tech I-6 Engine	DDD = 5-Speed HD Manual Transmission DDK = 5-Speed HD Manual Transmission DDQ = 5-Speed Manual Transmission DEH = 6-Speed Manual NSG370 Transmission DG6 = 4-Spd. Automatic 42RLE Transmission