
Power Distribution Center Relays and Fuses
Figure 8-505



ITEM	PART NUMBER	QTY	LINE	SERIES	BODY	ENGINE	TRANS	TRIM	DESCRIPTION
1	J4004642	1							POWER DISTRIBUTION CENTER, Serviced in Headlamp to Dash Harness, (NOT SERVICED)
2	04671168	AR							RELAY, Mini, ABS Pump, Clutch, Heater & Foglamp
3	04638271	1	J		77				RELAY PACKAGE, Electrical
-4	04798112	1					DG0		SEAL
5	06102075AA	1	J			ER0	DG0		FUSE CARTRIDGE, 20 Amp
6	06102076AA	1	J			ER0	DG0		FUSE CARTRIDGE, 30 Amp
7	04868008AA	1	J						FUSE CARTRIDGE, 40 Amp
8	06102078AA	1	J			ER0	DBB		FUSE CARTRIDGE, 50 Amp
9	000ATM10	2							FUSE, Mini, 10 AMP, Red
10									FUSE, Mini, 15 AMP, Light Blue
	000ATM15	1	J			ER0	DG0		
		1	J		77, 78	ED0	DBB		
11	06101488	1					DG0		FUSE, Mini, 20 AMP, Yellow
12									COVER, Power Distribution Center
	05134137AA	1	J		77, 78	ED0	DBB		
		1	J			ER0	DG0		
		1	J			ER0	DBB		

WRANGLER (TJ)

SERIES	LINE	BODY	ENGINE	TRANSMISSION
H = HIGHLINE	J = JEEP - 4WD	77 = OPEN BODY 2-DOOR	ED1 = 2.4L 4 Cyl DOHC 16v SMPI Engine	DDD = 5-Speed HD Manual Transmission
L = LOWLINE	U = JEEP - 4WD (RHD)	78 = OPEN BODY 2-DOOR	ERH = 4.0L Power Tech I-6 Engine	DDK = 5-Speed HD Manual Transmission
M = MEDIUM				DDQ = 5-Speed Manual Transmission
P = PREMIUM				DEH = 6-Speed Manual NSG370 Transmission
S = SPORT				DG6 = 4-Spd. Automatic 42RLE Transmission

AR = use ase required - = Non illustrrated part

<< RETURN TO GROUP INDEX