
Sensors Engine 4.0L [ER0]
Figure 8-610



ITEM	PART NUMBER	QTY	LINE	SERIES	BODY	ENGINE	TRANS	TRIM	DESCRIPTION
1	05149059AA	1				ER0			SWITCH, Oil Pressure
2	05149034AA	1				ER0			SENSOR, Camshaft
-3	33004242	1				ER0			CLAMP, Distributor, Cam sensor mounting
-4	J3181288	1				ER0			GASKET, Distributor, Cam sensor mounting
5	53010624AC	1				ER0			DRIVE, OIL PUMP
6	53010625AA	1				ER0			CAP, Protective
7									SENSOR, Crankshaft
	04727451AA	1				ER0	DBB		
		1				ER0	DG0		
-8	06501957	1				ER0			SCREW
9	56028364AA	1				ER0			SENSOR, Air Temperature
10	56044544AA	1				ER0			SENSOR, Manifold Absolute Pressure
-11	06504512	2				ER0			SCREW, Pan Head, Map Sensor attaching
12	05019411AC	1				ER0			SENSOR KIT, Throttle Position
13	56027873	1				ER0			SENSOR, Coolant Temperature
14	53009672	1				ER0			CONNECTOR, Emission Hose, MAP Sensor hose

WRANGLER (TJ)

SERIES	LINE	BODY	ENGINE	TRANSMISSION
H = HIGHLINE L = LOWLINE M = MEDIUM P = PREMIUM S = SPORT	J = JEEP - 4WD U = JEEP - 4WD (RHD)	77 = OPEN BODY 2-DOOR 78 = OPEN BODY 2-DOOR	ED1 = 2.4L 4 Cyl DOHC 16v SMPI Engine ERH = 4.0L Power Tech I-6 Engine	DDD = 5-Speed HD Manual Transmission DDK = 5-Speed HD Manual Transmission DDQ = 5-Speed Manual Transmission DEH = 6-Speed Manual NSG370 Transmission DG6 = 4-Spd. Automatic 42RLE Transmission

AR = use ase required - = Non illustrrated part

<< RETURN TO GROUP INDEX