
Instrument Panel
Figure 08A-110



ITEM	PART NUMBER	QTY	LINE	SERIES	BODY	ENGINE	TRANS	TRIM	DESCRIPTION
1									COVER, Instrument Panel
	5EU50XDVAF	1							[DV]
	5EU50ZJ3AF	1							[J3]
2	06506081AA	6							NUT, U, M6x1.00 Multi-UNut
3	34201416	2							NUT, Hex Flange, M8x1.25
4	06035369	4							SCREW, Piercing, .164-15x1.25, Speaker Bezel to Instrument Panel
5									NUT/SPRING, "U"1THD, For .164-15 Screw
	06035638	6	J						Duct to Instrument Panel
		6	U		77				Duct to Instrument Panel
6									BEZEL, Speaker
	5DP16XDV	1							[DV], Right
	5DP16ZJ3	1							[J3], Right
	5DP17XDV	1							[DV], Left
	5DP17ZJ3	1							[J3], Left
7	06503175	5							CLIP, Quarter Panel, I/Panel, M8.20x17.00
8	06507008AA	6							SCREW AND WASHER, Truss Head, M6x1x30, M6x1.00x30.00, Instrument Panel To Cowl
9									BEZEL, Instrument Cluster
	5GW62CD-KAB	1							[JBD]
	5GW62DX9AB	1							
10									SCREW
	06034949	3							Center Bezel To I/P
		5							Cluster Bezel To I/P
11	06101945	4							SCREW, M4.2x1.70x15.00
12									NUT, U, M6x1
	06101308	2	J						Bracket to Instrument Panel
		2	U		77				Bracket to Instrument Panel
13									SCREW AND WASHER, Hex Head, M6x1x20
	06100566	2	U		77				
		2	J						

WRANGLER (TJ)

SERIES	LINE	BODY	ENGINE	TRANSMISSION
H = HIGHLINE L = LOWLINE M = MEDIUM P = PREMIUM S = SPORT	J = JEEP - 4WD U = JEEP - 4WD (RHD)	77 = OPEN BODY 2-DOOR 78 = OPEN BODY 2-DOOR	ED1 = 2.4L 4 Cyl DOHC 16v SMPI Engine ERH = 4.0L Power Tech I-6 Engine	DDD = 5-Speed HD Manual Transmission DDK = 5-Speed HD Manual Transmission DDQ = 5-Speed Manual Transmission DEH = 6-Speed Manual NSG370 Transmission DG6 = 4-Spd. Automatic 42RLE Transmission