
Crankshaft, Piston and Torque Converter, 4.0L (ERH)
Figure 4.0L-410



ITEM	PART NUMBER	QTY	LINE	SERIES	BODY	ENGINE	TRANS	TRIM	DESCRIPTION
25	04736448AA	1				ER0	DG0		PLATE, Drive Plate
26	J3214094	1				ER0	DG0		PLATE, Drive Plate Backing
27	05093944AB	1				ER0	DG6		CONVERTER PACKAGE, Torque
28	J3151407	6				ER0	DG0		BOLT, Hex Head, .50-20x.56
29									PISTON PIN AND ROD
	04798329AC	6				ER0			B Size, 3.872
	04798330AC	6				ER0			C Size, 3.8746
	04798331AC	6				ER0			D Size, 3.8750
	04798332AC	6				ER0			E Size, 3.8754
	04798333AC	6				ER0			F Size, 3.8758
30	04798333AC	6							PIN, Piston, Serviced in Piston Assembly, (NOT SERVICED),
31	04798878	1				ER0	DBB		RING PACKAGE, Piston, Standard Size Complete Engine
32	04798878	1							ROD, Connecting, Serviced in Piston Assembly, (NOT SERVICED)
-33	05018594AB	2				ER0			SEAL PACKAGE, Crankshaft

WRANGLER (TJ)

SERIES	LINE	BODY	ENGINE	TRANSMISSION
H = HIGHLINE L = LOWLINE M = MEDIUM P = PREMIUM S = SPORT	J = JEEP - 4WD U = JEEP - 4WD (RHD)	77 = OPEN BODY 2-DOOR 78 = OPEN BODY 2-DOOR	ED1 = 2.4L 4 Cyl DOHC 16v SMPI Engine ERH = 4.0L Power Tech I-6 Engine	DDD = 5-Speed HD Manual Transmission DDK = 5-Speed HD Manual Transmission DDQ = 5-Speed Manual Transmission DEH = 6-Speed Manual NSG370 Transmission DG6 = 4-Spd. Automatic 42RLE Transmission

AR = use ase required - = Non illustrrated part

<< RETURN TO GROUP INDEX