






Group - 24

Air Conditioning & Heater



024-100 Air Conditioner and Heater Units 	**024-200** Air Conditioner and Heater Plumbing 	**024-300** Air Conditioner and Heater Controls 	**024-400** Air Conditioning Compressor 
024-500 Air Conditioning Compressor Mounting 	**024-600** Air Ducts and Outlets 		

Group - 24 Air Conditioning & Heater

Illustration Title — Group-Fig. No.

Air Conditioner and Heater Units
Heater Unit, LHD ..... Fig. 24 - 110
Heater Unit, RHD ..... Fig. 24 - 120
HVAC Unit, LHD ..... Fig. 24 - 130
HVAC Unit, RHD ..... Fig. 24 - 140

Air Conditioner and Heater Plumbing
Hoses, Heater 2.4L Engine ..... Fig. 24 - 210
Hoses, Heater 4.0L Engine, LHD ..... Fig. 24 - 220
Hoses, Heater 4.0L Engine, RHD ..... Fig. 24 - 230
Plumbing, HVAC 2.4L Engine ..... Fig. 24 - 240
Plumbing, HVAC 4.0L Engine, LHD ..... Fig. 24 - 250
Plumbing, HVAC 4.0L Engine, RHD ..... Fig. 24 - 260
Seals, A/C Condenser ..... Fig. 24 - 270

Air Conditioner and Heater Controls
Control, Heater And A/c ..... Fig. 24 - 310

Air Conditioning Compressor
Compressor, Air Conditioning 2.4L [ED0] Engine ..... Fig. 24 - 410
Compressor, Air Conditioning 4.0L [ER0] Engine ..... Fig. 24 - 420

Air Conditioning Compressor Mounting
Compressor, Mounting 2.4L Engine ..... Fig. 24 - 520
Compressor, Mounting 4.0L Engine ..... Fig. 24 - 530

Air Ducts and Outlets
Ducts, Heater and A/C ..... Fig. 24 - 610