Symptom:
P0441-EVAP PURGE SYSTEM PERFORMANCE

When Monitored and Set Condition:

P0441-EVAP PURGE SYSTEM PERFORMANCE

When Monitored: Cold start test. Engine Running. Small Leak Test Passed.

Set Condition: The PCM activates the EVAP Purge solenoid gradually increasing to maximum flow. During flow, the PCM looks for the NVLD switch to close. If the PCM does not see the NVLD switch close at maximum flow an error is detected. Two Trip Fault.

POSSIBLE CAUSES
GOOD TRIP EQUAL TO ZERO
VEHICLE HISTORY AND SERVICE BULLETIN INVESTIGATION
CHECKING EVAP PURGE SOLENOID FUNCTIONALITY
EVAP PURGE SOLENOID VACUUM SUPPLY
NVLD SWITCH OPERATION
VERIFY NVLD OPERATION

TEST	ACTION	APPLICABILITY
1	Start by reading PCM DTC(s) and record the related Freeze Frame data in any DTC(s) are present. Check the vehicle repair history. If the vehicle has a repair history that pertains to the customer's current complaint, review the repair. Inspect the vehicle for any aftermarket accessories that may have been installed incorrectly. Check for any service bulletin(s) related to the customer's complaint or DTC(s). If a service bulletin applies, follow the instructions per service bulletin. Did the service bulletin repair the customer's complaint? Yes → Testing Complete. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 2	All
2	Check for any related TSBs before continuing. **NOTE: If any of the following DTCs are set (P0443, P0452, P0453, P0498 or P0499) diagnose them first before continuing with P0441.** Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. Is the Good Trip Counter displayed and equal to zero? Yes → Go To 3 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5.	All