P0453-NVLD PRESSURE SWITCH STUCK OPEN — Continued

TEST	ACTION	APPLICABILITY
6	Measure the resistance between the (K107) NVLD Switch Signal circuit and the (K106) NVLD Sol Control circuit in the NVLD electrical harness connector. Is the resistance below 5.0 ohms? Yes → Repair the short between the (K107) NVLD Switch Signal circuit and the (K106) NVLD Solenoid Control circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 7	All
7	Measure the resistance between the (Z913) Ground circuit and ground. Is the resistance below 5.0 ohms? Yes → Go To 8 No → Repair the open in the (Z913) Ground circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
8	**NOTE: Before continuing, check the PCM harness connector terminals for corrosion, damage, or terminal push out. Repair as necessary.** Using the schematics as a guide, inspect the wire harness and connectors. Pay particular attention to all Power and Ground circuits. If there are no possible causes remaining, view repair. Repair Replace and program the Powertrain Control Module per Service Information. Perform POWERTRAIN VERIFICATION TEST VER - 5.	All