## Symptom:

## P0480-COOLING FAN NO.1 CONTROL CIRCUIT

**When Monitored and Set Condition:**

**P0480-COOLING FAN NO.1 CONTROL CIRCUIT**

When Monitored: With the ignition on. Battery voltage greater than 10 volts.

Set Condition: An open or shorted circuit is detected in the radiator fan relay control circuit.

| POSSIBLE CAUSES |
|---|
| LOW SPEED RADIATOR FAN RELAY OPERATION |
| LOW SPEED RADIATOR FAN RELAY |
| (F20) FUSED IGNITION SWITCH OUTPUT CIRCUIT |
| (A16) FUSED B+ CIRCUIT |
| (N201) LOW SPEED RAD FAN RELAY CONTROL CIRCUIT OPEN |
| (N201) LOW SPEED RAD FAN RELAY CONTROL CIRCUIT SHORTED TO GROUND |
| PCM |

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 1 | Ignition on, engine not running.<br>With the DRBIII®, actuate the Low Speed Radiator Fan Relay.<br>Is the Radiator Fan Relay cycling on and off?<br><br>Yes → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure).<br>Perform POWERTRAIN VERIFICATION TEST VER - 5.<br><br>No → Go To 2 | All |
| 2 | Turn the ignition off.<br>Remove the Low Speed Radiator Fan Relay from the PDC.<br>Measure the resistance of the Low Speed Radiator Fan Relay Coil by measuring between the (F20) Fused Ignition Switch terminal and the (N201) Control circuit terminal at the Relay .<br>Is the resistance between 60 and 80 ohms?<br><br>Yes → Go To 3<br><br>No → Replace the Low Speed Radiator Fan Relay.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |