P0501-VEHICLE SPEED SIGNAL PERFORMANCE — Continued

TEST	ACTION	APPLICABILITY
3	Turn the ignition off. Connect the PCM harness connector. Ignition on, engine not running. Measure the voltage on the (F856) 5-volt Supply circuit in the Vehicle Speed Sensor harness connector. Is the voltage between 4.5 to 5.2 volts? Yes → Go To 4 No → Go To 7	All
4	With the DRBIII®, monitor the Vehicle Speed Sensor voltage with the Sensor harness connector disconnected. Is the voltage above 1.2 volts? Yes → Replace the Vehicle Speed Sensor. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 5	All
5	Turn the ignition off. Disconnect the C1 and C2 PCM harness connectors. Measure the resistance between ground and the (K75) Vehicle Speed Sensor Signal circuit at the Vehicle Speed Sensor harness connector. Is the resistance below 100 ohms? Yes → Repair the excessive resistance between ground and the (K75) VSS Signal circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 6	All
6	Measure the resistance between the (K75) VSS Signal circuit and the (K900) Sensor ground circuit in the Vehicle Speed Sensor harness connector. Is the resistance below 100 ohms? Yes → Repair the short between the (K900) Sensor ground and the (K75) VSS Signal circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 9	All
7	Turn the ignition off. Disconnect the C1 PCM harness connector. **CAUTION: DO NOT PROBE THE PCM HARNESS CONNECTORS. PROBING THE PCM HARNESS CONNECTORS WILL DAMAGE THE PCM TERMINALS RESULTING IN POOR TERMINAL TO PIN CONNECTION. INSTALL MILLER SPECIAL TOOL #8815 TO PERFORM DIAGNOSIS.** Measure the resistance of the (F856) 5-volt Supply circuit from the Vehicle Speed Sensor harness connector to the appropriate terminal of special tool #8815. Is the resistance below 5.0 ohms? Yes → Go To 8 No → Repair the excessive resistance in the (F856) 5-volt Supply circuit. Perform POWERTRAIN VERIFICATION TEST VER - 5.	All