Symptom:

P0572-BRAKE SWITCH NO.1 CIRCUIT LOW

When Monitored and Set Condition:

P0572-BRAKE SWITCH NO.1 CIRCUIT LOW

When Monitored: Ignition on.

Set Condition: When the PCM recognizes Brake Switch #1 is mechanically stuck in the low/on position. One Trip Fault. Three Global Good Trips to Clear.

POSSIBLE CAUSES
GOOD TRIP EQUAL TO ZERO
BRAKE LAMP SWITCH OPERATION
(B15) BRAKE SWITCH NO.1 SIGNAL CIRCUIT SHORTED TO GROUND
PCM

TEST	ACTION	APPLICABILITY
1	**NOTE: Verify battery voltage is greater than 10 volts.** With the DRBIII®, read DTCs and record the related Freeze Frame data. Is the Good Trip Counter displayed and equal to zero? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 4.	All
2	Turn the ignition off. Remove the Brake Lamp Switch and disconnect the harness connector. Measure the resistance between the (Z249) Ground circuit terminal and the (B15) Brake Switch No.1 Signal terminal at the Brake Lamp Switch. Apply and release the brake pedal plunger while monitoring the ohmmeter. Does the resistance change from below 5.0 ohms to an open circuit? Yes → Go To 3 No → Replace the Brake Lamp Switch. Perform POWERTRAIN VERIFICATION TEST VER - 4.	All
3	Turn the ignition off. Disconnect the C3 PCM harness connector. Measure the resistance between ground and the (B15) Brake Switch No.1 Signal circuit in the Brake Lamp Switch harness connector. Is the resistance below 100 ohms? Yes → Repair the short to ground in the (B15) Brake Switch No.1 Signal circuit. Perform POWERTRAIN VERIFICATION TEST VER - 4. No → Go To 4	All