Symptom:

P0688-ASD RELAY SENSE CIRCUIT LOW

When Monitored and Set Condition:

P0688-ASD RELAY SENSE CIRCUIT LOW

When Monitored: With ignition key on. Battery voltage greater than 10 volts.

Set Condition: No voltage sensed at the PCM when the ASD relay is energized for 3.075 seconds. Three good trips to clear the MIL.

POSSIBLE CAUSES
VERIFY ASD DTC
ASD RELAY
(A209) FUSED B+ CIRCUITS
(K334) ASD RELAY OUTPUT CIRCUIT OPEN (NO START)
(K334) ASD RELAY OUTPUT CIRCUIT SHORTED TO GROUND
(K334) ASD RELAY OUTPUT CIRCUIT OPEN (START)
PCM

TEST	ACTION	APPLICABILITY
1	**NOTE: Diagnose P0685 - Auto Shutdown Relay Control Circuit first if set along with this DTC.** With the DRBIII®, erase the DTC. Attempt to start the engine. If the engine will not start, crank the engine for at least 15 seconds. It may be necessary to repeat several times. Does the DTC reset? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
2	Attempt to start the engine. Does the engine start? Yes → Go To 3 No → Go To 4	All