Symptom List:

P0883-TCM POWER INPUT HIGH
P0891-TRANSMISSION RELAY ALWAYS ON

Test Note: All symptoms listed above are diagnosed using the same tests. The title for the tests will be P0883-TCM POWER INPUT HIGH.

When Monitored and Set Condition:

P0883-TCM POWER INPUT HIGH

When Monitored: When the ignition is turned from the ″off″ position to the ″run″ position and/or the ignition is turned from the ″crank″ position to the ″run″ position.

Set Condition: This DTC set if the Transmission Control Module (TCM) senses greater than 3 volts at the Transmission Control Relay Output circuits at the TCM prior to the TCM energizing the relay. Note: Due to the integration of the Powertrain and Transmission Control Modules, the transmission part of the PCM has its own specific power and ground circuits.

P0891-TRANSMISSION RELAY ALWAYS ON

When Monitored: When the ignition is turned from the OFF position to the RUN position and/or the ignition is turned from the CRANK position to RUN position.

Set Condition: This DTC is set if the Transmission Control Module senses greater than 3.0 volts at the Transmission Control Relay Output terminal of the TCM prior to the TCM energizing the Transmission Control Relay.

POSSIBLE CAUSES
INTERMITTENT WIRING AND CONNECTORS
TRANSMISSION CONTROL RELAY STUCK CLOSED
TRANSMISSION CONTROL RELAY OUTPUT CIRCUIT SHORT TO VOLTAGE
TRANSMISSION RELAY CONTROL CIRCUIT SHORT TO VOLTAGE
TRANSMISSION CONTROL MODULE