## P1776-SOLENOID SWITCH VALVE LATCHED IN LR POSITION — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 9 | Turn the ignition off to the lock position.<br>Disconnect the PCM harness connector.<br>Disconnect the Transmission Solenoid/Pressure Switch Assembly harness connector.<br>Remove the Transmission Control Relay.<br>**Note: Check connectors - Clean/repair as necessary.**<br>**CAUTION: DO NOT PROBE THE PCM HARNESS CONNECTORS. PROBING THE PCM HARNESS CONNECTORS WILL DAMAGE THE PCM TERMINALS RESULTING IN POOR TERMINAL TO PIN CONNECTION. INSTALL MILLER SPECIAL TOOL #8815 TO PERFORM DIAGNOSIS.**<br>Connect a jumper wire between the Fused B+ circuit and Transmission Control Relay Output circuit at the Transmission Control Relay connector.<br>Ignition on, engine not running.<br>Measure the voltage of the L/R Pressure Switch Sense circuit.<br>Is the voltage above 0.5 volt?<br><br>Yes → Repair the L/R Pressure Switch Sense circuit for a short to voltage.<br>Perform 42RLE (NGC) TRANSMISSION VERIFICATION TEST - VER 1.<br><br>No → Go To 10 | All |
| 10 | Using the schematics as a guide, inspect the wiring and connectors. Repair as necessary. Pay particular attention to all power and ground circuits.<br>If there are no possible causes remaining, view repair.<br><br>Repair<br>Replace the Powertrain Control Module per the Service Information. WITH THE DRBIII® PERFORM QUICK LEARN AND REPROGRAM PINION FACTOR.<br>Perform 42RLE (NGC) TRANSMISSION VERIFICATION TEST - VER 1. | All |
| 11 | The conditions necessary to set this DTC are not present at this time.<br>Test Drive and verify if the transmission is launching in 2nd gear and/or no TCC engagement.<br>With the DRBIII®, check the EATX EVENT DATA to help identify the conditions in which the DTC was set.<br>Are there 2nd gear launches and/or no TCC engagement?<br><br>Yes → Disassemble and inspect the Valve Body per the Service Information. Inspect the Solenoid Switch Valve for sticking in its bore and repair or replace as necessary.<br>Perform 42RLE (NGC) TRANSMISSION VERIFICATION TEST - VER 1.<br><br>No → Test Complete. | All |