Sensors Engine 4.0L [ER0]
Figure 008-610



ITEM	PART NUMBER	QTY	LINE	SERIES	BODY	ENGINE	TRANS	TRIM	DESCRIPTION
Notes:									
[ER0]=All 4.0L Engine									
[DG0]=All Automaic Transmissions									
1	4868 672AA	1				ER0			SWITCH, Oil Pressure
2	5149 034AA	1				ER0			SENSOR, Camshaft
-3	3300 4242	1				ER0			CLAMP, Distributor, Cam sensor mounting
-4	J318 1288	1				ER0			GASKET, Distributor, Cam sensor mounting
5	53010 624AC	1				ER0			DRIVE, OIL PUMP
6									SENSOR, Crankshaft
	4727 451AA	1				ER0			
		1				ER0			
-7	6501 957	1				ER0			SCREW
8	5602 7872	1				ER0			SENSOR, Air Temperature
9	56044 544AA	1				ER0			SENSOR, Manifold Absolute Pressure
-10	6504 512	2				ER0			SCREW, Pan Head, Map Sensor attaching
11	5019 411AC	1				ER0			SENSOR KIT, Throttle Position
12	5602 7873	1				ER0			SENSOR, Coolant Temperature
13	5300 9672	1				ER0			CONNECTOR, Emission Hose, MAP Sensor hose

JEEP WRANGLER (TJ)

SERIES	LINE	BODY	ENGINE	TRANSMISSION
H = Sport	J = Wrangler 4WD	77 = 93.4 WB	ED1, ED0 = 2.4L DOHC	DGG, DGD = 32RH 3 Spd. Auto.
L = SE	U = Wrangler 4WD (RHD)		ERH = 4.0L Power Tech	DDD = 5 Speed HD Manual
M = X				DG0 = Auto. Trans.
P = Sahara				DBB = Manual Trans.
S = Rubicon				DDK = 5 Speed Manual