# Wiring--Headlamp / Dash Panel
## Figure 008-1305




| ITEM | PART NUMBER | QTY | LINE | SERIES | BODY | ENGINE | TRANS | TRIM | DESCRIPTION |
|---|---|---|---|---|---|---|---|---|---|
| 1 | | | | | | | | | WIRING, Headlamp to Dash |
| | 56051 474AA | 1 | J | | | ER0 | | | [BGA,BRW] |
| | 56051 475AA | 1 | J | | | ER0 | | | [BGA,BRW] |
| | 56051 476AA | 1 | J | | | ER0 | | | [NHM,BGA,BRW] |
| | 56051 477AA | 1 | J | | | ER0 | | | [NHM,BGA,BRW] |
| | 56051 478AA | 1 | J | | 77, 78 | ER0 | | | [BRW,DSE] |
| | 56051 479AA | 1 | J | | 77, 78 | ER0 | | | [BRW,DSE] |
| | 56051 480AA | 1 | J | | | ER0 | | | [BGK] |
| | 56051 481AA | 1 | J | | | ER0 | | | [BGK] |
| | 56051 482AA | 1 | J | | | ED0 | | | [BGA,HA0] |
| | 56051 483AA | 1 | J | | | ED0 | | | [BGA,HA0] |
| | 56051 484AA | 1 | J | | | ED0 | | | [BGA,HC0] |
| | 56051 485AA | 1 | J | | | ED0 | | | [BGA,HC0] |
| | 56051 486AA | 1 | U | | 77 | ER0 | | | [BGA,BRW] |
| | 56051 490AA | 1 | J | | | ER0 | | | [BRW,DSE,LMK] |
| | 56051 500AA | 1 | J | | | ER0 | | | [BRW,DSE,LMK] |
| | 56051 501AA | 1 | J | | | ER0 | | | [LMK,BGA,BRW] |
| | 56051 502AA | 1 | J | | | ER0 | | | [LMK,BGA,BRW] |
| | 56051 503AA | 1 | J | | | ER0 | | | [LMK,BGK] |
| | 56051 504AA | 1 | J | | | ER0 | | | [LMK,BGK] |
| | 56051 507AA | 1 | J | | | ED0 | | | [BGA,LMK,HC0] |
| | 56051 508AA | 1 | J | | | ED0 | | | [BGA,LMK,HC0] |
| | 56051 509AA | 1 | J | | | ER0 | | | [BGA,BRW], Export |
| | 56051 510AA | 1 | J | | | ER0 | | | [BGA,BRW], Export |
| | 56051 511AA | 1 | J | | | ER0 | | | [NHM,BGA,BRW], Export |
| | 56051 512AA | 1 | J | | | ER0 | | | [NHM,BGA,BRW], Export |
| | 56051 513AA | 1 | J | | | ER0 | | | [BGK], Export |
| | 56051 514AA | 1 | J | | | ER0 | | | [BGK], Export |
| | 56051 515AA | 1 | U | | 77 | ER0 | | | [BGA], Export |
| | 56051 516AA | 1 | U | | 77 | ER0 | | | [BGA], Export |
| | 56051 517AA | 1 | U | | 77 | ER0 | | | [BGK], Export |
| | 56051 518AA | 1 | U | | 77 | ER0 | | | [BGK], Export |
| | 56051 519AA | 1 | J | | 77, 78 | ED0 | | | [BGA,HA0], Export |
| | 56051 520AA | 1 | J | | 77, 78 | ED0 | | | [BGA,HC0], Export |
| | 56051 857AA | 1 | | | | | | | [AHF] |
| 2 | | | | | | | | | POWER DISTRIBUTION CENTER, Serviced in wiring assembly only, (NOT SERVICED) (Not Serviced) |
| 3 | 5134 137AA | 1 | J | | | ER0 | | | COVER, Power Distribution Center |
| 4 | 56010 210AB | 1 | | | | | | | BRACKET, Power Distribution Center |

**JEEP WRANGLER (TJ)**

| SERIES | LINE | BODY | ENGINE | TRANSMISSION |
|---|---|---|---|---|
| H = Sport | J = Wrangler 4WD | 77 = 93.4 WB | ED1, ED0 = 2.4L DOHC | DGG, DGD = 32RH 3 Spd. Auto. |
| L = SE | U = Wrangler 4WD (RHD) | | ERH = 4.0L Power Tech | DDD = 5 Speed HD Manual |
| M = X | | | | DG0 = Auto. Trans. |
| P = Sahara | | | | DBB = Manual Trans. |
| S = Rubicon | | | | DDK = 5 Speed Manual |

**AR = Use as required - = Non illustrated part # = New this model year** **August 27, 2004**

« RETURN TO GROUP INDEX »