Instrument Panel
Figure 08A-110



ITEM	PART NUMBER	QTY	LINE	SERIES	BODY	ENGINE	TRANS	TRIM	DESCRIPTION
NOTES:									
[DBB] = All Manual Transmissions									
[DG0] = All Automatic Transmissions									
1									COVER, Instrument Panel
	5EU50 XDVAF	1							[DV]
	5EU50 ZJ3AF	1							[J3]
2	6506 081AA	6							NUT, U, M6x1.00 Multi-UNut
3	3420 1416	2							NUT, Hex Flange, M8x1.25
4	6035 369	4							SCREW, Piercing, .164-15x1.25, Speaker Bezel to Instrument Panel
5									NUT/SPRING, "U"1THD, For .164-15 Screw
	6035 638	6	J						Duct to Instrument Panel
		6	U		77				Duct to Instrument Panel
6									BEZEL, Speaker
	5DP1 6XDV	1							[DV], Right
	5DP1 6ZJ3	1							[J3], Right
	5DP1 7XDV	1							[DV], Left
	5DP1 7ZJ3	1							[J3], Left
7	6503 175	5							CLIP, Quarter Panel, I/Panel, M8. 20x17.00
8	6507 008AA	6							SCREW AND WASHER, Truss Head, M6x1x30, M6x1.00x30.00, Instrument Panel To Cowl
9	5GW62 DX9AB	1							BEZEL, Instrument Cluster
10									SCREW
	6034 949	5							Cluster Bezel To I/P
		3							Center Bezel To I/P
11	6101 945	4							SCREW, M4.2x1.70x15.00
12	6101 308	2	J						NUT, U, M6x1, Bracket to Instrument Panel, Passenger Air Bag Door
13									SCREW AND WASHER, Hex Head, M6x1x20
	6101 455	2	J						
		2	U		77				
14	5HG72 DX9AA	1							BEZEL, Instrument Panel, Center
-15	4731 028	3							BUMPER, Center Bezel
16	5511 5652	1							MAT, Console Cup Holder, Center Tray Rubber Insert
17	4524 342	2							CLIP, Speaker
18									COVER, Instrument Panel, Steering Column Opening

JEEP WRANGLER (TJ)

SERIES	LINE	BODY	ENGINE	TRANSMISSION
H = Sport	J = Wrangler 4WD	77 = 93.4 WB	ED1, ED0 = 2.4L DOHC	DGG, DGD = 32RH 3 Spd. Auto.
L = SE	U = Wrangler 4WD (RHD)		ERH = 4.0L Power Tech	DDD = 5 Speed HD Manual
M = X				DG0 = Auto. Trans.
P = Sahara				DBB = Manual Trans.
S = Rubicon				DDK = 5 Speed Manual