Group – 014
Fuel



014–100 Tank, Fuel	**014–200** Fuel Tank Filler Tube	**014–300** Fuel Lines	**014–400** Fuel Rail
014–500 Fuel Pump and Sending Unit	**014–600** Throttle Body	**014–700** Throttle Controls	**014–800** Air Cleaner

Group – 014
Fuel

014–1000 Speed Control	**014–1100** Accelerator Pedal		