Seat Belts
Figure ITJ-710



ITEM	PART NUMBER	QTY	LINE	SERIES	BODY	ENGINE	TRANS	TRIM	DESCRIPTION
1									SEAT BELT, Front Outer
	5JC57 1X9AC	1			77			O0	Left,Export
	5JC56 1X9AC	1						O0	Right,Export
	5KK64 1X9AA	1						O0	Right
	5KK65 1X9AA	1						O0	Left
2	55217 173AD	2							ADJUSTER, Seat Belt Turning Loop
3	6036 108AA	2							SCREW, Pan Head
4									COVER, Turning Loop
	5HM32 DX9AC	1		S				O0	Right
		1		H, L, M				O0	Right
		1		P				O0	Right
	5HM33 DX9AC	1		S				O0	Left
		1		H, L, M				O0	Left
		1		P				O0	Left
5									SEAT BELT, Front Inner
	5HS49 1X9AE	1	J		77			H6	Driver
		1	U		77			H6	Driver
		1	J		78			S5	Driver
		1	J		77			S5	Driver
		1	U		77			P5	Driver
		1	J		77, 78			P5	Driver
		1	U		77			S5	Driver
		1	J		77			Q5	Driver
	5HS50 1X9AE	1	J		77, 78			P5	Passenger
		1	J		77			Q5	Passenger
		1	U		77			S5	Passenger
		1	J		77			S5	Passenger
		1	J		78			S5	Passenger
		1	U		77			P5	Passenger
		1	U		77			H6	Passenger
		1	J		77			H6	Passenger
6									BOLT, Seat Belt, Front Traveling Inboard Buckle Mounting
	5093 709AA	2	J		77			H6	
		2	U		77			H6	
		2	J		77, 78			P5	
		2	U		77			P5	
		2	J		77			Q5	
		2	J		78			S5	
		2	J		77			S5	
		2	U		77			S5	
7									SEAT BELT, Rear Outer

JEEP WRANGLER (TJ)

SERIES	LINE	BODY	ENGINE	TRANSMISSION
H = Sport	J = Wrangler 4WD	77 = 93.4 WB	ED1, ED0 = 2.4L DOHC	DGG, DGD = 32RH 3 Spd. Auto.
L = SE	U = Wrangler 4WD (RHD)		ERH = 4.0L Power Tech	DDD = 5 Speed HD Manual
M = X				DG0 = Auto. Trans.
P = Sahara				DBB = Manual Trans.
S = Rubicon				DDK = 5 Speed Manual

AR = Use as required - = Non illustrated part # = New this model year

August 27, 2004

« RETURN TO GROUP INDEX »