## Symptom:
## CLUSTER MESSAGE MISMATCH

**When Monitored and Set Condition:**

**CLUSTER MESSAGE MISMATCH**

When Monitored: After the MIC bulb test is completed, the ACM compares the Lamp Request by ACM, On or Off, and the Lamp on by MIC, On or Off, PCI Bus messages. Each message is transmitted one time per second or when a change in the lamp state occur.

Set Condition: If the Lamp Request by ACM, On or Off, and the Lamp on by MIC, On or Off, messages do not match, the code will set.

| POSSIBLE CAUSES |
|---|
| MIC DIAGNOSTIC CODES |
| CLUSTER MESSAGE MISMATCH |
| STORED CODE OR INTERMITTENT CONDITION |
| ACM, CLUSTER MESSAGE MISMATCH |
| ACTIVE CODE PRESENT |

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 1 | Turn the ignition on.<br>Ensure the battery is fully charged.<br>**NOTE: For the purpose of this test, the AECM and ORC modules will be referred to as an ACM.**<br>SELECT ACTIVE or STORED DTC:<br>ACM - ACTIVE DTC<br>Go To 2<br>ACM - STORED DTC<br>Go To 5<br>**NOTE: When reconnecting Airbag system components, the ignition must be turned off and the battery must be disconnected.** | All |
| 2 | Turn the ignition on.<br>With the DRBIII®, read the MIC DTCs.<br>Does the DRBIII® display any active Diagnostic Codes?<br>Yes → Refer to symptom list for problems related to Instrument Cluster. Perform __AIRBAG VERIFICATION TEST - VER 1.<br>No → Go To 3 | All |