## Symptom:
## PASSENGER AIRBAG ON - OFF SWITCH OPEN

**When Monitored and Set Condition:**

**PASSENGER AIRBAG ON - OFF SWITCH OPEN**

When Monitored: With the ignition on, the PAB MUX Switch Sense circuit supplies a 3 to 10 ms pulse every 100 ms across the On or Off switch resistor to the MUX Switch Return circuit.

Set Condition: The code will set if the ACM senses an open or high resistance on the PAB MUX Switch Sense circuit or PAB MUX Switch Return circuit.

| POSSIBLE CAUSES |
|---|
| CHECKING EQUIPMENT |
| PAB ON - OFF SWITCH OPEN |
| SWITCH DISCONNECTED |
| PASSENGER AIRBAG MUX SWITCH CIRCUIT OPEN |
| ACM, PASSENGER ON - OFF SWITCH CIRCUIT OPEN |
| STORED CODE OR INTERMITTENT CONDITION |
| ACTIVE CODE PRESENT |

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 1 | Turn the ignition on.<br>**NOTE: Ensure that the battery is fully charged.**<br>**NOTE: For the purpose of this test, the AECM and ORC modules will be referred to as an ACM.**<br>SELECT ACTIVE or STORED DTC:<br>ACM - ACTIVE DTC<br>Go To 2<br>ACM - STORED DTC<br>Go To 7<br>**NOTE: When reconnecting Airbag system components, the ignition must be turned off and the battery must be disconnected.** | All |
| 2 | Is this vehicle equipped with a Passenger Airbag On - Off Switch?<br>Yes → Go To 3<br>No → With the DRBIII® in MISCELLANEOUS, read the Configure for Airbag ON - OFF Switch current status. Enter the number 1 and press enter to re configure the ACM for NO AIRBAG ON/OFF SWITCH.<br>Perform __AIRBAG VERIFICATION TEST - VER 1. | All |