## PASSENGER OFF INDICATOR CIRCUIT SHORT TO GROUND — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 10 | With the DRBIII®, record and erase all DTC's from all Airbag modules.<br>If equipped with Passenger Airbag On - Off switch, read the DTC's in all switch positions.<br>If any ACTIVE codes are present they must be resolved before diagnosing any stored codes.<br>**WARNING: TO AVOID PERSONAL INJURY OR DEATH, TURN THE IGNITION OFF, DISCONNECT THE BATTERY AND WAIT TWO MINUTES BEFORE PROCEEDING.**<br>Using the wiring diagram/schematic as a guide, inspect the wiring and connectors. Look for chaffed, pierced, pinched, or partially broken wires and broken, bent, pushed out, spread, corroded, or contaminated terminals.<br>The following additional checks may assist you in identifying a possible intermittent problem.<br>Reconnect any disconnected components and harness connector.<br>**WARNING: TO AVOID PERSONAL INJURY OR DEATH, TURN THE IGNITION ON, THEN RECONNECT THE BATTERY.**<br>With the DRBIII® monitor active codes as you work through the following steps.<br>**WARNING: TO AVOID PERSONAL INJURY OR DEATH, MAINTAIN A SAFE DISTANCE FROM ALL AIRBAGS WHILE PERFORMING THE FOLLOWING STEPS.**<br>Wiggle the wiring harness and connectors of the related airbag circuit or component. If codes are related to the Driver Airbag circuits, rotate the steering wheel from stop to stop.<br>IF only stored codes return continue the test until the problem area has been isolated In the previous steps you have attempted to recreate the conditions responsible for setting active DTC in question.<br>Are any ACTIVE DTCs present?<br>Yes → Select appropriate symptom from Symptom List.<br>No → No problem found at this time. Erase all codes before returning vehicle to customer. | All |