RIGHT FRONT SENSOR CIRCUIT FAILURE 19
RIGHT REAR SENSOR CIRCUIT FAILURE 19
LEFT FRONT SENSOR SIGNAL FAILURE 22
LEFT REAR SENSOR SIGNAL FAILURE 22
RIGHT FRONT SENSOR SIGNAL FAILURE. 22
RIGHT REAR SENSOR SIGNAL FAILURE 22
PUMP MOTOR NOT WORKING PROPERLY 25
SYSTEM OVER VOLTAGE. 29
SYSTEM UNDER VOLTAGE 31
*ABS WARNING INDICATOR ALWAYS ON 33
*ABS WARNING INDICATOR INOPERATIVE 35
*BRAKE LAMP SWITCH. 37
*FRONT AXLE LOCK INDICATOR REMAINS FLASHING 38
*NO RESPONSE FROM CONTROLLER ANTILOCK BRAKE 40
*REAR AXLE LOCK INDICATOR REMAINS FLASHING 42
*REAR AXLE LOCK INOPERATIVE. 45

VERIFICATION TESTS
VERIFICATION TESTS 47

8.0 COMPONENT LOCATIONS 49

8.1 CONTROLLER ANTILOCK BRAKE 49
8.2 DATA LINK CONNECTOR 49
8.3 G-SWITCH. 49
8.4 FUSES & RELAYS 50
8.5 WHEEL SPEED SENSORS 50
8.6 WHEEL SPEED SENSOR CONNECTORS. 50
8.7 BRAKE SWITCHES 51
8.7.1 PARKING BRAKE 51
8.7.2 BRAKE SWITCH 51

9.0 CONNECTOR PINOUTS 53

ABS PUMP MOTOR (COMPONENT SIDE) - 2 WAY 53
AXLE LOCK SWITCH (OFF-ROAD PACKAGE) - 8 WAY. 53
BRAKE LAMP SWITCH - GRAY 6 WAY 53
BRAKE WARNING INDICATOR SWITCH - BLACK 2 WAY 54
CLUTCH PEDAL POSITION SWITCH (M/T) - BLACK 2 WAY. 54
CONTROLLER ANTILOCK BRAKE - 25 WAY 54
DATA LINK CONNECTOR - BLACK 16 WAY 55
FRONT LOCKER INDICATOR SWITCH (OFF-ROAD PACKAGE) - BLACK 2 WAY . .55
FRONT LOCKER PUMP (OFF-ROAD PACKAGE) - LT. GRAY 3 WAY 55
FUSES (FB). 57
G-SWITCH - 3 WAY 57
INSTRUMENT CLUSTER C1 - 12 WAY 57
INSTRUMENT CLUSTER C2 - 16 WAY 58
LEFT FRONT WHEEL SPEED SENSOR - 2 WAY 58
LEFT FRONT WHEEL SPEED SENSOR (COMPONENT SIDE) - 2 WAY 58
LEFT REAR WHEEL SPEED SENSOR - 2 WAY 59
LEFT REAR WHEEL SPEED SENSOR (COMPONENT SIDE) - 2 WAY. 59
FUSES (PDC) 61
ANTILOCK BRAKE RELAY 61