

LEFT REAR WHEEL SPEED SENSOR

LEFT REAR WHEEL SPEED SENSOR - 2 WAY

CAV	CIRCUIT	FUNCTION
1	B3 18DG/YL	LEFT REAR WHEEL SPEED SENSOR (-)
2	B4 18DG/GY	LEFT REAR WHEEL SPEED SENSOR (+)



LEFT REAR WHEEL SPEED SENSOR (COMPONENT SIDE)

LEFT REAR WHEEL SPEED SENSOR (COMPONENT SIDE) - 2 WAY

CAV	CIRCUIT	FUNCTION
1	LG/DB	LEFT REAR WHEEL SPEED SENSOR (-)
2	LG	LEFT REAR WHEEL SPEED SENSOR (+)