AUTOMATIC TRANSMISSION - 42RLE (Continued)

*ELEMENTS IN USE AT EACH POSITION OF SELECTOR LEVER*

| Shift Lever Position | INPUT CLUTCHES | | | HOLDING CLUTCHES | |
|---|---|---|---|---|---|
| | Underdrive | Overdrive | Reverse | 2/4 | Low/Reverse |
| P - PARK | | | | | X |
| R - REVERSE | | | X | | X |
| N - NEUTRAL | | | | | X |
| OD - OVERDRIVE | | | | | |
| First | X | | | | X |
| Second | X | | | X | |
| Direct | X | X | | | |
| Overdrive | | X | | X | |
| D - DRIVE* | | | | | |
| First | X | | | | X |
| Second | X | | | X | |
| Direct | X | X | | | |
| L - LOW* | | | | | |
| First | X | | | | X |
| Second | X | | | X | |
| Direct | X | X | | | |
| * Vehicle upshift and downshift speeds are increased when in these selector positions. | | | | | |

The process of elimination can be used to detect any unit which slips and to confirm proper operation of good units. Road test analysis can diagnose slipping units, but the cause of the malfunction cannot be determined. Practically any condition can be caused by leaking hydraulic circuits or sticking valves.

## DIAGNOSIS AND TESTING - HYDRAULIC PRESSURE TESTS

Pressure testing is a very important step in the diagnostic procedure. These tests usually reveal the cause of most transmission problems.

Before performing pressure tests, be certain that fluid level and condition, and shift cable adjustments have been checked and approved. Fluid must be at operating temperature (150 to 200 degrees F.).

Install an engine tachometer, raise vehicle on hoist which allows the wheels to turn, and position tachometer so it can be read.

Using special adapters L-4559, attach 300 psi gauge(s) C-3293SP to the port(s) required for test being conducted.

Test port locations are shown in the Pressure Taps graphic. (Fig. 8)




***Fig. 8 Pressure Taps***

1 - TORQUE CONVERTER CLUTCH OFF
2 - REVERSE
3 - LOW/REVERSE
4 - 2/4
5 - UNDERDRIVE
6 - TORQUE CONVERTER CLUTCH ON
7 - OVERDRIVE