CHR ProxMox installation



help.mikrotik.com/docs/spaces/ROS/pages/48660553/CHR+ProxMox+installation

Log in

Created by Oskars K., last updated by Guntis G. on Feb 08, 2024 3 minute read

Create a new guest with the system disk and other devices as required.

Then you have to manually upload the CHR disk (in qcow format) on the ProxMox host.

Use scp or any other comparable tool as that will use SSH for the upload and it does not require any additional configuration.

Either copy the file to the server and then manually edit the VM's .conf file or replace the previously created system image file used for booting the guest.

Local storage on ProxMox is in /var/lib/vz directory. There should be a subdirectory called *images* with a directory for each VM (named by the VM number). You can copy the files directly there.

To add the existing file to the VM, edit the VM's .conf file directly. Look in /etc/pve/gemu-server/ for a file with the VM number followed by .conf.

Note: It's a good idea to create a second test VM so you can refer to it's.conf file to make sure you get the syntax right

Alternative approach

- Create Basic VM via ProxMox web GUI.
- Make sure that VM storage is on local storage (this way there will be no need to work with the LVM config side, and the disk image can be moved later on to LVM or other desired storage if needed).
- Log into ProxMox host via SSH and navigate to the VM image directory. Default local storage is located in: var/lib/vz/images/(VM_ID)
- Via scp, wget or any other tool download CHR raw image (.img file) into this directory.
- Now convert the CHR raw image to qcow2 format using qemu-img tool:

qemu-img convert -f raw -0 qcow2 chr-6.40.3.img vm-(VM_ID)-disk-1.qcow2

Bash script approach

If you have access to the ProxMox host then CHR VM can also be created guickly via BASH script. Below is an example of one such script.

What this script does:

- Stores tmp files in: /root/temp dir.
- Downloads raw image archive from MikroTik download page.
- Converts image file to qcow format.
- Creates a basic VM that is attached to the MGMT bridge.

```
#!/bin/bash
#vars
version="nil"
vmID="nil"
echo "########## Start of Script ############
## Checking if temp dir is available..."
if [ -d /root/temp ]
then
   echo "-- Directory exists!"
else
   echo "-- Creating temp dir!"
   mkdir /root/temp
fi
# Ask user for version
echo "## Preparing for image download and VM creation!"
read -p "Please input CHR version to deploy (6.38.2, 6.40.1, etc):" version
# Check if image is available and download if needed
if [ -f /root/temp/chr-$version.img ]
then
   echo "-- CHR image is available."
else
   echo "-- Downloading CHR $version image file."
   cd /root/temp
   echo "-----
   wget https://download.mikrotik.com/routeros/$version/chr-$version.img.zip
   unzip chr-$version.img.zip
   echo "-----
_ _ _ "
fi
# List already existing VM's and ask for vmID
echo "== Printing list of VM's on this hypervisor!"
qm list
echo ""
read -p "Please Enter free vm ID to use:" vmID
# Create storage dir for VM if needed.
if [ -d /var/lib/vz/images/$vmID ]
   echo "-- VM Directory exists! Ideally try another vm ID!"
   read -p "Please Enter free vm ID to use:" vmID
else
   echo "-- Creating VM image dir!"
   mkdir /var/lib/vz/images/$vmID
fi
# Creating qcow2 image for CHR.
echo "-- Converting image to qcow2 format "
qemu-img convert \
   -f raw \
   -0 qcow2 \
   /root/temp/chr-$version.img \
   /var/lib/vz/images/$vmID/vm-$vmID-disk-1.qcow2
# Creating VM
```

Useful tips

Useful snippet to clean up the BASH script from Windows formatting that may interfere with the script if it's edited on a Windows workstation:

```
sed -i -e 's/\r$//' *.sh
```